Philips
5.1 Home theater

DVD
USB 2.0
Karaoke

HTD5510



Powerful cinematic surround sound with deep sound

Bring the power of the cinema into your home! Pump up your home entertainment experience with speakers with double basspipes offering powerful 1000W surround sound and in Full HD 1080p with DVD Disc playback.

Great listening experience
- 1000W RMS power delivers great sound for movies and music
- Exposed speaker drivers for powerful surround sound
- Dolby Digital for ultimate movie experience

Designed to enhance your cinema at home
- Modern design to complement your home environment

Simply enjoy all your entertainment
- Audio in to enjoy music from iPod/iPhone/MP3 player
- EasyLink to control all HDMI CEC devices via a single remote
- HDMI for high definition movies and picture quality
- Plays DVD, VCD, CD and USB devices
- DivX Ultra Certified for enhanced DivX video playback
- Karaoke for endless singing entertainment at home

PHILIPS

Highlights

1000W RMS power



1000W RMS power delivers great sound for movies and music

Audio in



Audio in allows you to easily play your music directly from your iPod/iPhone/iPad, MP3 player, or laptop via a simple connection to your home cinema. Simply connect your audio device to the Audio in jack to enjoy your music with the superior sound quality of the Philips home cinema system.

DivX Ultra Certified



With DivX support, you are able to enjoy DivX encoded videos and movies from the Internet, including purchased Hollywood films, in the comfort of your living room. The DivX media format is an MPEG-4 based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW and DVD recordable disc for playback on your DivX Ultra Certified Philips Blu-ray or DVD player. DivX Ultra combines DivX playback with great features like integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.

Dolby Digital



Because Dolby Digital, the world's leading digital multi-channel audio standards, make use of the way the human ear naturally processes sound, you experience superb quality surround sound audio with realistic spatial cues.

EasyLink



EasyLink lets you control multiple devices like DVD players, Blu-ray players, soundbar speaker, Home theater and TV's etc. with one remote. It uses HDMI CEC industry-standard protocol to share functionality between devices through the HDMI cable. With one touch of a button, you can operate all your connected HDMI CEC enabled equipment simultaneously. Functions like standby and play can now be carried out with absolute ease.

Exposed speaker drivers



Exposed speaker drivers for powerful surround sound

HDMI for HD movies



HDMI is a direct digital connection that can carry digital HD video as well as digital multichannel audio. By eliminating the conversion to analog signals it delivers perfect picture and sound quality, completely free from noise. Movies in standard definition can now be enjoyed in true high definition resolution - ensuring more details and more true-to-life pictures.

Modern design

Modern design to complement your home environment

Plays it all



Play virtually any disc and any media devices you want - whether they be DVDs, VCDs, CDs or USB devices. Experience the unbeatable convenience of great playability, and the luxury of sharing media files on your TV or home theater system.

5.1 Home theater
DVD USB 2.0, Karaoke

HTD5510/94

Specifications

Sound
- Sound Enhancement: Night Mode
- Sound System: Dolby Digital 5.1
- Subwoofer output power: 166 W
- Equalizer settings: Gaming, Movie, Music, News, Original
- Center speaker output power: 166 W
- Satellite speaker output power: 4 x 166 W
- Total Power RMS @ 30% THD: 1000 W

Loudspeakers
- Loudspeaker types: 1 x Centre speaker, 4 x Satellite speakers
- Center speaker drivers: 1 x 3" Full range woofer
- Satellite speaker freq range: 150-20k Hz
- Satellite speaker impedance: 4 ohm
- Subwoofer freq range: 20-150 Hz
- Center speaker impedance: 4 ohm
- Subwoofer driver: 1 x 8" woofer
- Subwoofer type: Passive
- Center speaker freq range: 150-20k Hz
- Drivers per Satellite speaker: 1 x 3" Full range woofer
- Subwoofer impedance: 4 ohm

Connectivity
- Front Connections: Hi-Speed USB, Microphone In, Audio in
- Rear Connections: AUX IN 1, Composite video (CVBS) output, Digital optical in, HDMI 1.4 output (ARC), Mini Easy-Fit Speaker Jacks

Tuner/Reception/Transmission
- Tuner Bands: FM
- Number of Preset Channels: 40

Outer Carton
- EAN: 87 12581 68439 6
- Length: 59.6 cm
- Number of consumer packagings: 1
- Width: 39.4 cm
- Gross weight: 11.32 kg
- Height: 32.7 cm
- Nett weight: 10.1 kg
- Tare weight: 1.22 kg

Convenience
- EasyLink (HDMI-CEC): Audio Return Channel, Automatic audio input mapping, One touch play, One touch standby, Remote Control-Passthrough, System standby
- HDMI Features: Audio Return Channel (ARC)

Power
- Power consumption: 105 W
- Power supply: 220-240V, 50Hz
- Standby power consumption: < 0.5 W

Packaging dimensions
- Height: 39.4 cm
- Packaging type: Carton
- Type of shelf placement: Laying
- Width: 59.6 cm
- Depth: 32.7 cm
- Number of products included: 1
- EAN: 87 12581 68439 6
- Gross weight: 11.32 kg
- Nett weight: 10.1 kg
- Tare weight: 1.22 kg

Product dimensions
- Height: 5.8 cm
- Width: 36 cm
- Depth: 33.5 cm
- Weight: 2.4 kg

Accessories
- Compatible accessories: STS3001 Speaker stand
- Included accessories: Remote Control, AAA Battery (x1), Safety & Legal Leaflet, Trademarks Sheet, User Manual

Dimensions
- Center Speaker (W x H x D): 223 x 100 x 80 mm
- Center Speaker Weight: 0.65 kg
- Centre Speaker cable length: 2 m
- Front Speaker (W x H x D): 90 x 185 x 82 mm
- Subwoofer (W x H x D): 233 x 365 x 310 mm
- Front Speaker Weight: 0.53 kg
- Subwoofer Weight: 4.3 kg
- Front Speaker cable length: 3 m
- Rear Speaker (W x H x D): 90 x 185 x 82 mm
- Rear Speaker Weight: 0.53 kg
- Rear Speaker cable length: 7 m
- Subwoofer cable length: 3 m

Audio Playback
- Compression format: MP3, WMA
- MP3 bit rates: 32 - 320kbps

File Format
- Audio: mp3, wma
- Video: avi, divx, mpeg, mpg
- Picture: GIF, JPEG, BMP

Picture/Display
- Picture enhancement: Video upscaling

Optical Playback Media
- Playable Discs: CD, CDDA, CD-R/CD-RW, DVD, DVD +R/+RW, DVD -R/-RW, SVCD, VCD

Karaoke Playback
- Standard functions: Echo level control, Mic volume control, Pitch control

Still Picture Playback
- Picture Compression Format: BMP, GIF, JPEG, TIFF
- Picture Enhancement: Rotate, Zoom

Video Playback
- Compression formats: DivX Ultra, MPEG1, MPEG2

Issue date 2024-05-07
Version: 4.0.3
EAN: 87 12581 68439 6

© 2024 Koninklijke Philips N.V.
All Rights reserved.
Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com

* DivX, DivX Certified, and associated logos are trademarks of DivXNetworks, Inc. and are used under license.
* Dolby and the double-D symbol are registered trademarks of Dolby Laboratories Inc.

Always there to help you

Register your product and get support at
www.philips.com/welcome



HTD5510
HTD5540
HTD5570

User manual

PHILIPS

Contents

1 Important 2
Safety 2
Care for your product 3
Care of the environment 3

2 Your home theater 4
Main unit 4
Remote control 4
Connectors 5

3 Connect and set up 7
Connect speakers 7
Connect to TV 8
Connect audio from TV and other devices 9
Set up speakers 10
Set up EasyLink (HDMI-CEC control) 10

4 Use your home theater 12
Access the home menu 12
Discs 12
Data files 13
USB storage devices 14
Audio, video, and picture options 14
Radio 15
MP3 player 15
Karaoke 16
Choose sound 16

5 Change settings 18
Language settings 18
Picture and video settings 18
Audio settings 19
Parental control settings 19
Display settings 19
Energy saving settings 19
Restore default settings 20

6 Update software 21
Check software version 21
Update software through USB 21

7 Product specifications 22

8 Troubleshooting 24

9 Notice 26
Copyright 26
Trademarks 26

10 Language code 27

1 Important

Read and understand all instructions before you use your home theater. If damage is caused by failure to follow instructions, the warranty does not apply.

Safety

Risk of electric shock or fire!

- Never expose the product and accessories to rain or water. Never place liquid containers, such as vases, near the product. If liquids are spilt on or into the product, disconnect it from the power outlet immediately. Contact Philips Consumer Care to have the product checked before use.
- Never place the product and accessories near naked flames or other heat sources, including direct sunlight.
- Never insert objects into the ventilation slots or other openings on the product.
- Where the mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.
- Disconnect the product from the power outlet before lightning storms.
- When you disconnect the power cord, always pull the plug, never the cable.

Risk of short circuit or fire!

- Before you connect the product to the power outlet, ensure that the power voltage matches the value printed on the back or bottom of the product. Never connect the product to the power outlet if the voltage is different.

Risk of injury or damage to the home theater!

- For wall-mountable products, use only the supplied wall mount bracket. Secure the wall mount to a wall that can support the combined weight of the product and the wall mount. Koninklijke Philips Electronics N.V. bears no responsibility for improper wall mounting that results in accident, injury or damage.
- For speakers with stands, use only the supplied stands. Secure the stands to the speakers tightly. Place the assembled stands on flat, level surfaces that can support the combined weight of the speaker and stand.
- Never place the product or any objects on power cords or on other electrical equipment.
- If the product is transported in temperatures below 5°C, unpack the product and wait until its temperature matches room temperature before connecting it to the power outlet.
- Visible and invisible laser radiation when open. Avoid exposure to beam.
- Do not touch the disc optical lens inside the disc compartment.
- Parts of this product can be made of glass. Handle with care to avoid injury and damage.

Risk of overheating!

- Never install this product in a confined space. Always leave a space of at least four inches around the product for ventilation. Ensure curtains or other objects never cover the ventilation slots on the product.

Risk of contamination!

- Do not mix batteries (old and new or carbon and alkaine, etc.).
- Danger of explosion if batteries are incorrectly replaced. Replace only with the same or equivalent type.
- Remove batteries if they are exhausted or if the remote control is not to be used for a long time.
- Batteries contain chemical substances, they should be disposed of properly.

Risk of swallowing batteries!

- The product/remote control may contain a coin/button type battery, which can be swallowed. Keep the battery out of reach

of children at all times! If swallowed, the battery can cause serious injury or death. Severe internal burns can occur within two hours of ingestion.
- If you suspect that a battery has been swallowed or placed inside any part of the body, seek immediate medical attention.
- When you change the batteries, always keep all new and used batteries out of reach of children. Ensure that the battery compartment is completely secure after you replace the battery.
- If the battery compartment cannot be completely secured, discontinue use of the product. Keep out of reach of children and contact the manufacturer.



This is CLASS II apparatus with double insulation, and no protective earth provided.

Care for your product

- Do not insert any objects other than discs into the disc compartment.
- Do not insert warped or cracked discs into the disc compartment.
- Remove discs from the disc compartment if you are not using the product for an extended period of time.
- Use only microfiber cloth to clean the product.

Care of the environment



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products and batteries. The correct disposal of these products helps prevent potentially negative consequences on the environment and human health.
Your product contains batteries, which cannot be disposed of with normal household waste. Please inform yourself about the local rules on separate collection of batteries. The correct disposal of batteries helps prevent potentially negative consequences on the environment and human health.
Please visit www.recycle.philips.com for additional information on a recycling center in your area.

2 Your home theater

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your home theater at www.philips.com/welcome.

Main unit



1. **Disc compartment**
2. **Display panel**
3. **▲ (Open/Close)**
   Open or close the disc compartment, or eject the disc.
4. **▶II (Play/Pause)**
   Start, pause or resume play.
5. **SOURCE**
   Select an audio or video source for the home theater.
6. **⏻ (Standby-On)**
   Switch the home theater on or to standby.

Front panel display	Indication
HOME	Home
RAd IO	Radio
d ISC	Disc
AUX 1	Aux In
OPt 1	Optical In
AUd IO	Audio In
OPEN	Open
CLOSE	Close
LOAd	Load
rOGJS	Browse
PAUSE	Pause
----	Mute

Remote control

This section includes an overview of the remote control.



① ⏻ (Standby-On)
- Switch the home theater on or to standby.
- When EasyLink is enabled, press and hold for at least three seconds to switch all connected HDMI CEC compliant devices to standby.

② Source buttons
- **DISC**: Switch to disc source.Access or exit the disc menu when you play a disc.
- **AUDIO SOURCE**: Select an audio input source.
- **RADIO**: Switch to FM radio.
- **USB**: Switch to USB storage device.

③ Navigation buttons
- Navigate menus.
- In video mode, press left or right to fast backward or fast forward; press up or down to slow forward or slow backward (for DVD video only).
- In radio mode, press left or right to search a radio station; press up or down to fine tune a radio frequency.

④ OK
Confirm an entry.

⑤ ⮌ BACK
Return to a previous menu screen.

⑥ 🔈+/-
Increase or decrease volume.

⑦ 🔈× (Mute)
Mute or restore volume.

⑧ ⏮ / ⏭ (Previous/Next)
- Skip to the previous or next track, chapter or file.
- In radio mode, select a preset radio station.

⑨ Numeric buttons
Select an item to play.

⑩ SOUND
Select a sound mode.

⑪ SURR
Select surround sound or stereo sound.

⑫ ▶❚❚ (Play/Pause)
Start, pause or resume play.

⑬ ■ (Stop)
Stop play.

⑭ ☰ OPTIONS
Access more play options while playing a disc or a USB storage device.

⑮ ⏏ (Open/Close)
Open or close the disc compartment.

⑯ ⌂ (Home)
Access or exit the home menu.

⑰ AUDIO SYNC
- Select an audio language or channel.
- Press and hold to access audio delay setting, then press **Navigation buttons** (left/right) to delay the audio to match the video.

Connectors

This section includes an overview of the connectors available on your home theater.

Front

Front connectors



① ⇠ (USB)
Audio, video or picture input from a USB storage device.

② MIC
Audio input from a microphone.

③ AUDIO IN
Audio input from an MP3 player (3.5mm jack).

Back connectors



① AC MAINS
Connect the supplied AC power cable.

② SPEAKERS
Connect to the supplied speakers and subwoofer.

③ VIDEO OUT
Connect to the composite video input on the TV.

④ AUDIO IN-AUX
Connect to an analog audio output on the TV or an analog device.

⑤ DIGITAL IN-OPTICAL
Connect to an optical audio output on the TV or a digital device.

⑥ HDMI OUT (ARC)
Connect to the HDMI input on the TV.

⑦ FM ANTENNA
Connect the supplied antenna for radio reception.

3 Connect and set up

This section helps you connect your home theater to a TV and other devices, and then set it up.
For information about the basic connections of your home theater and accessories, see the quick start guide.

Note

- For identification and supply ratings, see the type plate at the back or bottom of the product.
- Before you make or change any connections, make sure that all devices are disconnected from the power outlet.

Connect speakers

The speaker cables are color-coded for easy connection. To connect a speaker to your home theater, match the color on the speaker cable to the color on the connector.

Speaker position plays a critical role in setting up a surround sound effect. For best effect, position all the speakers towards the seating position and place them close to your ear level (seated).



*The actual speaker shapes may vary from the illustration above.

Note

- Surround sound depends on factors such as room shape and size, type of wall and ceiling, windows and reflective surfaces, and speaker acoustics. Experiment with the speaker positions to find the optimum setting for you.

Follow these general guidelines for speakers placement.

1. Seating position:
   This is the center of your listening area.
2. **FRONT CENTER** (front center) speaker:
   Place the center speaker directly in front of the seating position, either above or below your TV.
3. **FRONT LEFT** (front left) and **FRONT RIGHT** (front right) speakers:
   Place the left and right speakers in the front, and at equal distance from the center speaker. Make sure that the left, right, and the center speakers are at equal distance from your seating position.
4. **REAR LEFT** (rear left) and **REAR RIGHT** (rear right) speakers:
   Place the rear surround speakers to the left and right side of your seating position, either in line with it or slightly behind it.

5 **SUBWOOFER** (subwoofer):
Place the subwoofer at least one meter to the left or right of the TV. Leave about 10-centimeter clearance from the wall.

Connect to TV

Connect your home theater to a TV to watch videos. You can listen to the TV audio through your home theater speakers.
Use the best quality connection available on your home theater and TV.

Option 1: Connect to TV through HDMI (ARC)

Best quality video
Your home theater supports HDMI version with Audio Return Channel (ARC). If your TV is HDMI ARC compliant, you can hear the TV audio through your home theater by using a single HDMI cable.



1 Using a High Speed HDMI cable, connect the **HDMI OUT (ARC)** connector on your home theater to the **HDMI ARC** connector on the TV.
- The **HDMI ARC** connector on the TV might be labeled differently. For details, see the TV user manual.

2 On your TV, turn on HDMI-CEC operations. For details, see the TV user manual.
- HDMI-CEC is a feature that enables CEC compliant devices that are connected through HDMI to be controlled by a single remote control, such as volume control for both the TV and the home theater. (see 'Set up EasyLink (HDMI-CEC control)' on page 10)

3 If you cannot hear the TV audio through your home theater, set up the audio manually. (see 'Set up the audio' on page 11)

Option 2: Connect to TV through standard HDMI

Best quality video
If your TV is not HDMI ARC compliant, connect your home theater to the TV through a standard HDMI connection.



1 Using a High Speed HDMI cable, connect the **HDMI OUT (ARC)** connector on your home theater to the **HDMI** connector on the TV.

2 Connect an audio cable to hear the TV audio through your home theater (see 'Connect audio from TV and other devices' on page 9).

3 On your TV, turn on HDMI-CEC operations. For details, see the TV user manual.
- HDMI-CEC is a feature that enables CEC compliant devices that are connected through HDMI to be controlled by a single remote control, such as volume control for both the TV and the home theater. (see 'Set up EasyLink (HDMI-CEC control)' on page 10)

4 If you cannot hear the TV audio through your home theater, set up the audio manually. (see 'Set up the audio' on page 11)

Note

- If your TV has a DVI connector, you can use an HDMI/DVI adapter to connect to TV. However, some of the features may not be available.

Option 3: Connect to the TV through composite video

Basic quality video

If your TV does not have HDMI connectors, use a composite video connection. A composite connection does not support high-definition video.



1 Using a composite video cable, connect the **VIDEO OUT** connector on your home theater to the **VIDEO IN** connector on the TV.
   - The composite video connector might be labeled **AV IN**, **COMPOSITE**, or **BASEBAND**.
2 Connect an audio cable to hear the TV audio through your home theater (see 'Connect audio from TV and other devices' on page 9).
3 When you watch TV programs, press **SOURCE** on your home theater repeatedly to select the correct audio input.
4 When you watch videos, switch your TV to the correct video input. For details, see the TV user manual.

Connect audio from TV and other devices

Play audio from TV or other devices through your home theater speakers.
Use the best quality connection available on your TV, home theater, and other devices.

Note

- When your home theater and TV are connected through HDMI ARC, an audio connection is not required (see 'Option 1: Connect to TV through HDMI (ARC)' on page 8).

Option 1: Connect audio through a digital optical cable

Best quality audio



1 Using an optical cable, connect the **OPTICAL** connector on your home theater to the **OPTICAL OUT** connector on the TV or other device.
   - The digital optical connector might be labeled **SPDIF** or **SPDIF OUT**.

Option 2: Connect audio through analog audio cables

Basic quality audio



1 Using an analog cable, connect the **AUX** connectors on your home theater to the **AUDIO OUT** connectors on the TV or other device.

Set up speakers

Set up the speakers manually to experience customized surround sound.

Before you start

Make the necessary connections described in the quick start guide, and then switch the TV to the correct source for your home theater.

1 Press ⌂ (**Home**).
2 Select **[Setup]**, and then press **OK**.
3 Select **[Audio]** > **[Speaker Setup]**.
4 Press the **Navigation buttons** and **OK** to select and change:
   - **[Speakers Volume]**: Set the volume level of each speaker.
   - **[Speakers Delay]**: Set the delay time for speakers which are placed closer to the seating position in order to obtain equal audio transmission from all the speakers.

Set up EasyLink (HDMI-CEC control)

This home theater supports Philips EasyLink, which uses the HDMI-CEC (Consumer Electronics Control) protocol. EasyLink-compliant devices that are connected through HDMI can be controlled by a single remote control.

Note

- Depending on the manufacturer, HDMI-CEC is known by many names. For information on your device, see the user manual of the device.
- Philips does not guarantee 100% interoperability with all HDMI-CEC devices.

Before you start

- Connect your home theater to the HDMI-CEC compliant device through HDMI connection.
- Make the necessary connections described in the quick start guide, and then switch the TV to the correct source for your home theater.

Enable EasyLink

1 Press ⌂ (**Home**).
2 Select **[Setup]**, and then press **OK**.
3 Select **[Video]**, and then press **OK**.
4 Select **[HDMI Setup]** > **[EasyLink Setup]** > **[EasyLink]** > **[On]**.
5 On your TV and other connected devices, turn on HDMI-CEC control. For details, see the user manual of the TV or other devices.
   - On your TV, set the audio output to 'Amplifier' (instead of TV speakers). For details, see the TV user manual.

EasyLink controls

With EasyLink, you can control your home theater, TV, and other connected HDMI-CEC compliant devices with a single remote control.

- **[One Touch Play]** (One-touch play): If one-touch play is enabled, press ⏻ (**Standby-On**) on the remote control of your home theater to wake up the TV from standby.
- **[One Touch Standby]** (One-touch standby): If one-touch standby is enabled, your home theater can switch to standby with the remote control of the TV or other HDMI-CEC devices.
- **[Sys Audio Control]** (System audio control): If system audio control is enabled, the audio of the connected device is output through your home theater speakers automatically when you play the device.
- **[Audio Mapping]** (Audio input mapping):If system audio control does not work, map the connected device to the correct audio input connector on your home theater. (see 'Set up the audio' on page 11)

Note

- To change the EasyLink control settings, press ⌂ (**Home**), select **[Setup]** > **[Video]** > **[HDMI Setup]** > **[EasyLink Setup]** > **[EasyLink]**.

Set up the audio

If you cannot hear the audio output of a connected device through your home theater speakers, do the following:

- Check that you have enabled EasyLink on all the devices, (see 'Set up EasyLink (HDMI-CEC control)' on page 10) and
- on your TV, set the audio output to "Amplifier" (instead of TV speakers). For details, see the TV user manual, and
- setup the EasyLink audio control.

1 Press ⌂ (**Home**).

2 Select **[Setup]**, and then press **OK**.

3 Select **[Video]**, and then press **OK**.

4 Select **[HDMI Setup]** > **[EasyLink Setup]** > **[Sys Audio Control]** > **[On]**.
   - To play the audio from the TV speakers, select **[Off]**, and skip the following steps.

5 Select **[HDMI Setup]** > **[EasyLink Setup]** > **[Audio Mapping]**.

6 Follow the onscreen instructions to map the connected device to the audio inputs on your home theater.
   - If you connect your home theater to the TV through an **HDMI ARC** connection, make sure that the TV audio is mapped to the ARC input on your home theater.

4 Use your home theater

This section helps you use the home theater to play media from a wide range of sources.

Before you start

- Make the necessary connections described in the Quick start guide and the user manual.
- Switch the TV to the correct source for the home theater.

Access the home menu

The home menu provides easy access to connected devices, setup and other useful features in your home theater.

1. Press ⌂ (**Home**).
   ↳ The home menu is displayed.
2. Press the **Navigation buttons** and **OK** to select the following:
   - **[DISC]**: Start disc play.
   - **[USB]**: Access the USB content browser.
   - **[Karaoke]**: Access Karaoke.
   - **[Setup]**: Access menus to change video, audio and other settings.
3. Press ⌂ (**Home**) to exit.

Discs

Your home theater can play DVDs, VCDs, and CDs. It can also play discs that you've made at home, such as CD-R discs of photos and music.

1. Insert a disc into the home theater.
2. If the disc does not play automatically, press **DISC** or select **[DISC]** from the home menu.
3. Press the play buttons to control play (see 'Play buttons' on page 12).

Play buttons

Button	Action
Navigation buttons	Navigate menus.
OK	Confirm an entry.
▶❚❚ (**Play/ Pause**)	Start, pause or resume play.
■	Stop play.
⏮ / ⏭	Skip to the previous or next track, chapter or file.
◀◀ / ▶▶	Fast backwards or fast forwards. Press repeatedly to change the search speed.
Navigation buttons (left/right)	Rotate the picture clockwise or counter-clockwise.
Navigation buttons (up/down)	Flip the picture vertically or horizontally.
DISC	Access or exit the disc menu.
AUDIO SYNC	Select an audio language or channel.
☰ **OPTIONS**	Access more options when you play your audio, video, or media files. (see 'Audio, video, and picture options' on page 14)

Synchronize picture and sound

If the audio and video are not synchronized, delay the audio to match the video.

1. While playing video, press and hold **AUDIO SYNC**.
   ↳ Audio sync menu is displayed.
2. Press the **Navigation buttons** (left/right) to synchronize the audio with the video, and then press **OK**.

Note

- Picture and sound can be synchronized through the setup menu, press ⌂ (**Home**), select **[Setup]** > **[Audio]** > **[Audio Sync]**.

Display menu for VCD and SVCD

Display the content menu on VCD and SVCD discs.

1. Press ⌂ (**Home**).
2. Select **[Setup]**, and then press **OK**.
3. Select **[Preferences]** > **[PBC]**.
   - **[PBC]**: Enable or disable the content menu navigation of VCD and SVCD discs with Play Back Control feature.

Data files

Your home theater can play pictures, audio and video files contained in a disc or a USB storage device. Before you play a file, check that the file format is supported by your home theater (see 'File formats' on page 22).

1. Play the files from a disc or USB storage device.
2. To stop play, press ■.
   - To resume the video from where you stopped, press ▶ (**Play**).
   - To play the video from the start, press **OK**.

Note

- To play DivX DRM protected files, connect your home theater to a TV through an HDMI cable.

Subtitles

If your video has subtitles in multiple languages, select a subtitle language.

Note

- Make sure that the subtitle file has the exact same name as the video file. For example, if the video file is named 'movie.avi', name the subtitle file as 'movie.srt' or 'movie.sub'.
- Your home theater supports the following file formats: .srt, .sub, .txt, .ssa, .ass, smi, and .sami. If the subtitles do not appear correctly, change the character set.

1. Press ☰ **OPTIONS**, and select a subtitle language under **SUBTITLE** option.
2. For DivX videos, if the subtitles do not appear correctly, continue the following steps to change the character set.
3. Press ⌂ (**Home**).
4. Select **[Setup]**, and then press **OK**.
5. Select **[Preferences]** > **[DivX Subtitle]**.
6. Select a character set that supports the subtitle.

Character Set	Language
[Standard]	English, Albanian, Danish, Dutch, Finnish, French, Gaelic, German, Italian, Kurdish (Latin), Norwegian, Portuguese, Spanish, Swedish and Turkish

VOD code for DivX

Before you purchase DivX videos and play them on your home theater, register the home theater on www.divx.com using the DivX VOD code.

1. Press ⌂ (**Home**).
2. Select **[Setup]**, and then press **OK**.
3. Select **[General]** > **[DivX(R) VOD Code]**.
   ↳ The DivX VOD registration code for your home theater is displayed.

USB storage devices

Enjoy pictures, audio, and video stored on a USB storage device such as an MP4 player.

What you need

- A USB storage device that is formatted for FAT or NTFS file system, and complies with the Mass Storage Class.
- A media file in one of the supported file formats. (see 'File formats' on page 22)

Note

- If you use a USB extension cable, USB HUB or USB multi-reader, the USB storage device may not be recognized.

1 Connect a USB storage device to the ⇢ (**USB**) connector on your home theater.

2 Press **USB**.
↳ A content browser is displayed.

3 Select a file and then press **OK**.

4 Use the play buttons to control play.

Audio, video, and picture options

Use advanced features when you play audio, video, or media files from a disc or a USB storage device.

Audio options

1 While playing audio, press ☰ **OPTIONS** repeatedly to select a repeat mode.

Video options

1 While viewing video, press ☰ **OPTIONS**.
↳ The video options menu is displayed. Depending on the video source, some options are not available.

2 Press the **Navigation buttons** buttons and **OK** to select and change:
- **[Info]**: Display the play information.
- **[PBC]**: Enable or disable the content menu navigation of VCD and SVCD discs with Play Back Control feature.
- **[Aspect ratio]**: Select a display ratio of picture that matches your TV screen.
- **[Repeat]**: Select a repeat play mode.
- **[Zoom]**: Zoom into a video scene or picture. Press the **Navigation buttons** (left/right) to select a zoom factor.
- **[Subtitle]**: Select subtitle language for video.
- **[Angle]**: Select video scenes recorded in different camera angels.
- **[Microphone]**: Turn the microphone on or off.
- **[Karaoke setup]**: Access the Karaoke setup menu.
- **[Vocal]**: Select a Karaoke audio mode, or turn off original vocals.

Picture options

1 While viewing pictures, press ☰ **OPTIONS**.

2 Press the **Navigation buttons** and **OK** to select and change:
- **[Color]**: Turn on or off the color mode.
- **[Photo preview]**: Display the thumbnail of photos.
- **[Repeat]**: Select a repeat mode for slideshow.
- **[Zoom]**: Zoom into a video scene or picture. Press the **Navigation buttons** (left/right) to select a zoom factor.

3 Press ⏮ / ⏭ to go to previous or next preview page.

4 Press the **Navigation buttons** and **OK** to select a picture.

Musical slideshow

If the picture and audio files are from the same disc or USB storage device, you can create a musical slideshow.

1. Select an audio track and then press **OK**.
2. Press **BACK** and then go to the picture folder.
3. Select a picture and then press **OK** to start the slideshow.
4. Press ■ to stop slideshow.
5. Press ■ again to stop music.

Radio

Listen to FM radio on your home theater, and store up to 40 radio stations.

Note

- AM and digital radio are not supported.
- If no stereo signal is detected, you are prompted to install the radio stations again.

1. Connect the FM antenna to the **FM ANTENNA** on your home theater.
   - For the best reception, place the antenna away from your TV or other sources of radiation.
2. Press **RADIO** to switch to radio source.
   - ↳ If you have already installed the radio stations, the last channel that you listened to is played.
   - ↳ If you have not installed any radio stations, the message **AUTO INSTALL...PRESS PLAY** appears on the display panel. Press ▶ (**Play**) to install radio stations.
3. Use the remote control to listen or to change radio stations.

Play buttons

Button	Action
⏮ / ⏭ or Alphanumeric buttons	Select a preset radio station.
Navigation buttons	Left/Right: Search for a radio station. Up/Down: Fine tune a radio frequency.
■	Press to stop the installation of radio stations. Press and hold to erase the preset radio station.
RADIO	**Manual**: 1) In radio mode, press **RADIO**. 2) When a radio frequency blinks, press **OK** to store the radio station. 3) Repeat step 1 and 2 to store other stations. **Automatic**: In radio mode, press and hold **RADIO** for three seconds to reinstall all the available radio station.

Tuning grid

In some countries, you can toggle the FM tuning grid between 50 kHz and 100 kHz.

1. Press **RADIO** to switch to radio source.
2. Press ■.
3. Press and hold ▶ (**Play**) to toggle between 50 kHz or 100 kHz.

MP3 player

Connect a MP3 player to play audio files.

What you need

- An MP3 player.
- A 3.5mm stereo audio cable.

1 Using the 3.5mm stereo audio cable, connect the MP3 player to the **AUDIO IN** connector on your home theater.
   - If you use 6.5mm stereo audio cable, connect the MP3 player to your home theater using a 3.5mm - 6.5mm converter jack.
2 Press **AUDIO SOURCE** repeatedly until **AUDIO IN** appears on the display panel.
3 Press the buttons on the MP3 player to select and play audio files.

Karaoke

Play a Karaoke disc on your home theater and sing along with the music.

What you need

- A Karaoke microphone.
- Karaoke discs.

Note

- To prevent loud feedback or unexpected noise, turn the microphone volume to the minimum before you connect the microphone to your home theater.

Play karaoke music

1 While playing a karaoke disc, press ⌂ (**Home**).
   ↳ The home menu is displayed.
2 Select **[Karaoke]**, and then press **OK**.
   ↳ The karaoke setup menu is displayed.
3 Press the **Navigation buttons** (up/down) and **OK** to change the following settings:
   - **[Microphone]**: Turn the microphone on or off.
   - **[Mic Volume]**: Change the microphone volume.
   - **[Echo Level]**: Change the echo level.
   - **[Karaoke Scoring]**: Select a difficulty level to score your singing. After a song ends, a score is given.
   - **[Karaoke Idol]**: Have a Karaoke contest with your friends. Follow the on-screen instructions to start the contest.
   - **[Key Shift]**: Change the pitch to match your voice.
   - **[Vocal]**: Select a Karaoke audio mode, or turn off original vocals.

Choose sound

This section helps you choose the ideal sound for your video or music.

Sound mode

Select predefined sound modes to suit your video or music.

1 Press **SOUND** repeatedly to select a sound mode.
   - **[Movie Mode]**: Enjoy a cinematic audio experience, specially enhanced for movies.
   - **[Music Mode]**: Recreate the original recording environment of your music, in the studio or at a concert.
   - **[Original]**: Experience the original sound of your movies and music, without added sound effects.
   - **[News]**: Hear every word with optimized speech and clear vocals.
   - **[Gaming]**: Enjoy thrilling arcade sounds, ideal for action-packed video games or loud parties.

Surround sound mode

Experience an immersive audio experience with surround sound modes.

1 Press **SURR** repeatedly to select a surround mode.
   - **[Multi Channel]**: Traditional 5.1 channel for a more relaxing cinematic experience.

- **[Stereo]**: Two-channel stereo sound. Ideal for listening to music.

Note

- If the audio source is a 2.1 channel, multi-channel mode will output 5-channel stereo sound.

5 Change settings

The home theater settings are already configured for optimal performance. Unless you have a reason to change a setting, we recommend that you keep the default setting.

Note

- You cannot change a setting that is grayed out.
- To return to the previous menu, press BACK. To exit the menu, press (Home).

Language settings

Onscreen display language

1 Press (Home).
2 Select **[Setup]** and then press **OK**.
3 Select **[General]** and then press **OK**.
   - **[OSD Language]**: Select a display language for menu.

Disc language

1 Press (Home).
2 Select **[Setup]** and then press **OK**.
3 Select **[Preferences]** and then press **OK**.
   - **[Audio]**: Select an audio language for discs.
   - **[Subtitle]**: Select a subtitle language for discs.
   - **[Disc Menu]**: Select a menu language for discs.

Note

- If your preferred disc language is not available, select **[Others]** from the list, and enter the 4-digit language code found at the end of this user manual (see 'Language code' on page 27).
- If you select a language that is not available on a disc, the home theater uses the default language of the disc.

Picture and video settings

1 Press (Home).
2 Select **[Setup]** and then press **OK**.
3 Select **[Video]** and then press **OK**.
   - **[TV System]**: Select a video format supported by the TV.
   - **[TV Display]**: Select a picture format to fit the TV screen.
   - **[Picture Setting]**: Select animation for the slide show.
   - **[HD JPEG]**: Enable this feature to view high-definition JPEG pictures through HDMI connection.
   - **[HDMI Setup]**: Access the following setup through HDMI connection.
     * **[Resolution]**: Select a resolution for high definition videos.
     * **[HDMI Deep Color]**: Recreate the natural world on your TV screen by displaying vivid images using billion colors. Your home theater must be connected to a Deep Color enabled TV through an HDMI cable.
     * **[Wide Screen]**: Select a display format for wide screen videos.
     * **[EasyLink Setup]**: Set up EasyLink control (see 'Set up EasyLink (HDMI-CEC control)' on page 10).

Note

- If you change a setting, make sure that the TV supports the new setting.

Audio settings

1 Press ⌂ (**Home**).
2 Select **[Setup]** and then press **OK**.
3 Select **[Audio]** and then press **OK**.
- **[HDMI Audio]**: Set the HDMI audio output from your TV, or disable HDMI audio output from the TV.
- **[Audio Sync]**: Set audio delay if audio and video cannot be matched.
- **[Speaker Setup]**: Set up speakers for best surround sound experience.
- **[Sound Mode]**: Select a predefined sound mode to suit your video and music.
- **[Treble/Bass]**: Set the high frequency (treble) and low frequency (bass) settings of the home theater.
- **[Night Mode]**: Select quiet or full dynamic sound. Night mode decreases the volume of loud sounds and increases volume of sounds such as speech. Applicable to Dolby Digital encoded DVD discs only.

Parental control settings

Password and Ratings

1 Press ⌂ (**Home**).
2 Select **[Setup]** and then press **OK**.
3 Select **[Preferences]** and then press **OK**.
- **[Password]**: Set or change your password for parental control access. If you do not have a password or have forgotten your password, enter 000000.
- **[Parental Control]**: Enable maturity-based restricted access for playback of DVD-video that are recorded with ratings. To play discs irrespective of the rating, select **[8 Adult]**.

Lock disc

1 Press ⌂ (**Home**).
2 Select **[Setup]** and then press **OK**.
3 Select **[General]** and then press **OK**.
- **[Disc Lock]**: Lock the disc to restrict play. You can lock up to 20 discs on your home theater.

Note

- To play a locked disc, follow the onscreen instructions to enter the password, and then press **OK**.

Display settings

1 Press ⌂ (**Home**).
2 Select **[Setup]** and then press **OK**.
3 Select **[Preferences]** and then press **OK**.
- **[PBC]**: Enable or disable the content menu navigation of VCD and SVCD discs with Play Back Control feature.

Energy saving settings

1 Press ⌂ (**Home**).
2 Select **[Setup]** and then press **OK**.
3 Select **[General]** and then press **OK**.
- **[Display Dim]**: Set the brightness of the home theater front panel display.
- **[Sleep Timer]**: Switch the home theater to standby mode after the elapsed time.
- **[Auto Standby]**: Switch the home theater to standby mode after 25 minutes of no activity when in disc or USB mode.

Restore default settings

1 Press ⌂ (**Home**).
2 Select **[Setup]** and then press **OK**.
3 Select **[Preferences]** > **[Default]**, and then press **OK**.
4 Follow the onscreen message to restore default setting.
   ↳ Your home theater is reset to its default settings, except for password, parental control and disc lock settings.

6 Update software

Philips continually tries to improve its products. To get the best features and support, update your home theater with the latest software.

Compare the version of your current software with the latest version on www.philips.com/support. If the current version is lower than the latest version available on the Philips support website, upgrade your home theater with the latest software.

Caution

- Do not install a lower version of software than the current version installed on your product. Philips is not liable for problems caused due to software downgrade.

Check software version

Check the version of the current software installed on your home theater.

1. Press ⌂ (**Home**).
2. Select **[Setup]** and then press **OK**.
3. Select **[Preferences]** > **[Version Info]**.
   ↳ The software version is displayed.

Update software through USB

What you need

- A USB flash drive that is FAT or NTFS-formatted, with at least 75MB of memory. Do not use a USB hard drive.
- A computer with Internet access.
- An archive utility that supports the ZIP file format.

Step 1: Download the latest software

1. Connect a USB flash drive to your computer.
2. In your web browser, go to www.philips.com/support.
3. At the Philips Support website, find your product and locate the **Software and drivers**.
   ↳ The software update is available as a zip file.
4. Save the zip file in the root directory of your USB flash drive.
5. Use the archive utility to extract the software update file in the root directory.
6. Disconnect the USB flash drive from your computer.

Step 2: Update the software

Caution

- Do not switch off the home theater or remove the USB flash drive during the update.

1. Connect the USB flash drive containing the downloaded file to your home theater.
   - Make sure that the disc compartment is closed and there is no disc inside.
2. Switch your TV to the correct source for your home theater.
3. Follow the onscreen instructions to confirm the update.
   ↳ Once complete, the home theater automatically switches off and restarts. If it does not, disconnect the power cord for a few seconds and then reconnect it.

7 Product specifications

Note

- Specifications and design are subject to change without notice.

Region codes

The type plate on the back or bottom of the home theater shows which regions it supports.

Country	DVD
Europe, United Kingdom	
Asia Pacific, Taiwan, Korea	
Latin America	
Australia, New Zealand	
Russia, India	
China	

Media formats

- DVD-Video, DVD+R/+RW, DVD-R/-RW, DVD+R/-R DL, CD-R/CD-RW, Audio CD, Video CD/SVCD, Picture files, MP3 media, WMA media, DivX media, USB storage device

File formats

- Audio: .mp3, .wma
- Video: .avi, .divx, .mpg, .mpeg,
- Picture: .jpg, .jpeg

Amplifier

- Total output power: 1000W RMS (30% THD)
- Frequency response: 20 Hz-20 kHz / ±3 dB
- Signal-to-noise ratio: > 65 dB (CCIR) / (A-weighted)
- Input sensitivity:
  - AUX: 2 V
  - AUDIO IN: 1 V

Video

- Signal system: PAL / NTSC/Multi
- HDMI output: 480i/576i, 480p/576p, 720p, 1080i, 1080p

Audio

- S/PDIF Digital audio input:
  - Optical: TOSLINK
- Sampling frequency:
  - MP3: 32 kHz, 44.1 kHz, 48 kHz
  - WMA: 44.1 kHz, 48 kHz
- Constant bit rate:
  - MP3: 32 kbps - 320 kbps
  - WMA: 64 kbps - 192 kbps

Radio

- Tuning range:
  - Europe/Russia/China: FM 87.5-108 MHz (50 kHz)
  - Asia Pacific/Latin America: FM 87.5-108 MHz (50/100 kHz)
- Signal-to-noise ratio: FM 50 dB
- Frequency response: FM 200 Hz-12.5 kHz / ±6 dB

USB

- Compatibility: Hi-Speed USB (2.0)

- Class support: USB Mass Storage Class (MSC)
- File system: FAT16, FAT32, NTFS
- USB port: 5V ⎓, 500mA

Main unit

- Power supply:
  - Europe/China/Russia/India: 220-240V~, 50 Hz
  - Latin America/Asia Pacific: 110-127 V/220-240 V~, 50-60 Hz
- Power consumption: 140 W
- Standby power consumption: ≤ 0.5 W
- Dimensions (WxHxD):
  360 x 58 x 325 mm
- Weight: 2.3 kg

Subwoofer

- Output power: 166 W RMS (30% THD)
- Impedance: 4 ohm
- Speaker drivers: 203 mm (8") woofer
- Dimensions (WxHxD):
  233 x 365 x 310 mm
- Weight: 4.82 kg
- Cable length: 3.3 m

Speakers

Center speaker:

- Output power: 166 W RMS (30% THD)
- Speaker impedance: 4 ohm
- Speaker drivers: 1 x 78 mm (3") full range
- Dimensions (WxHxD): 223 x 100 x 80 mm
- Weight: 0.65 kg
- Cable length: 2.25 m

Front/Rear speaker:

- Output power: 4 x 166 W RMS (30% THD)
- Speaker impedance: 4 ohm
- Speaker drivers: 1 x 78 mm (3") full range
- Dimensions (WxHxD):
  - **HTD5510**: 90 x 185 x 82 mm (front/rear)
  - **HTD5540**: 90 x 185 x 82 mm (front); 247 x 1090 x 242 mm (rear)
  - **HTD5570**: 247 x 1090 x 242 mm (front/rear)
- Weight (front):
  - **HTD5510**: 0.53 kg/each
  - **HTD5540**: 0.53 kg/each
  - **HTD5570**: 2.66 kg/each
- Weight (rear):
  - **HTD5510**: 0.56 kg/each
  - **HTD5540/HTD5570**: 2.72 kg/each
- Cable length (front): 3.25 m
- Cable length (rear): 10.25 m

Remote control batteries

- 1 x AAA-R03-1.5 V

Laser

- Type: Semiconductor laser GaAlAs (CD)
- Wave length: 650-662 nm (DVD), 785-795 nm (CD)
- Output power: 6 mW (DVD), 7 mW (VCD/CD)
- Beam divergence: 60 degrees.

8 Troubleshooting

Warning

- Risk of electric shock. Never remove the casing of the product.

To keep the warranty valid, never try to repair the product yourself.
If you have problems using this product, check the following points before you request service. If you still have a problem, get support at www.philips.com/support.

Main unit

The buttons on the home theater do not work.

- Disconnect the home theater from the power supply for a few minutes, then reconnect.

Picture

No picture.

- Make sure that the TV is switched to the correct source for the home theater.

No picture on a TV connected through HDMI.

- Make sure that the HDMI cable is not faulty. If it is faulty, replace it with a new cable.
- Wait for 10 seconds for auto recovery, or change the HDMI video setting (see 'Picture and video settings' on page 18).

Disc does not play high-definition video.

- Make sure that the disc contains high-definition video.
- Make sure that the TV supports high-definition video.
- Use an HDMI cable to connect to the TV.

Sound

No sound from home theater speakers.

- Connect the audio cable from your home theater to your TV or other devices. However, you do not need a separate audio connection when the home theater and TV are connected through an **HDMI ARC** connection.
- Set up the audio for the connected device (see 'Set up the audio' on page 11).
- Reset your home theater to its factory settings (see 'Restore default settings' on page 20), and then switch it off and switch on again.
- On your home theater, press **SOURCE** repeatedly to select the correct audio input.

Distorted sound or echo.

- If you play audio from the TV through the home theater, make sure that the TV is muted.

Audio and video are not synchronized.

- 1) Press and hold **AUDIO SYNC**. 2) Press the **Navigation buttons** (left/right) within five seconds to synchronize the audio with the video.

Play

Cannot play a disc.

- Clean the disc.
- Make sure that the home theater supports the type of disc (see 'Media formats' on page 22).
- Make sure that the home theater supports the region code of the disc.
- If the disc is a DVD±RW or DVD±R disc, make sure that it is finalized.

Cannot play a DivX file.

- Make sure that the DivX file is encoded according to the 'Home Theater Profile' with the DivX encoder.
- Make sure that the DivX file is complete.

DivX subtitles do not display correctly.

- Make sure that the subtitle file name is the same as the movie file name (see 'Subtitles' on page 13).
- Select the correct character set (see 'Subtitles' on page 13).

Cannot read the contents of a USB storage device.

- Make sure that the format of the USB storage device is compatible with the home theater.
- Make sure that the file system on the USB storage device is supported by the home theater.

'input invalid' or 'x' sign appears on the TV.

- The operation is not possible.

EasyLink does not work.

- Make sure that the home theater is connected to a Philips brand EasyLink TV, and the EasyLink option is turned on (see 'Set up EasyLink (HDMI-CEC control)' on page 10).
- For TVs from different manufacturers, the HDMI CEC could be called differently. Check the TV user manual on how to enable it.

When you switch on the TV, the home theater automatically switches on.

- This behavior is normal when you are using Philips EasyLink (HDMI-CEC). To make the home theater work independently, switch off EasyLink.

9 Notice

This section contains the legal and trademark notices.

Copyright



This item incorporates copy protection technology that is protected by U.S. patents and other intellectual property rights of Rovi Corporation. Reverse engineering and disassembly are prohibited.

Trademarks

Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.

DivX ®, DivX Ultra ®, DivX Certified ® and associated logos are trademarks of Rovi Corporation or its subsidiaries and are used under license.
DivX Ultra ® Certified to play DivX ® video with advanced features and premium content.
ABOUT DIVX VIDEO: DivX ® is a digital video format created by DivX, LLC, a subsidiary of Rovi Corporation. This is an official DivX Certified ® device that plays DivX video. Visit divx.com for more information and software tools to convert your files into DivX videos.
ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified ® device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies. To obtain your registration code, locate the DivX VOD section in your device setup menu. Go to vod.divx.com for more information on how to complete your registration.

The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.



10 Language code

Abkhazian	6566
Afar	6565
Afrikaans	6570
Amharic	6577
Arabic	6582
Armenian	7289
Assamese	6583
Avestan	6569
Aymara	6589
Azerhaijani	6590
Bahasa Melayu	7783
Bashkir	6665
Belarusian	6669
Bengali	6678
Bihari	6672
Bislama	6673
Bokmål, Norwegian	7866
Bosanski	6683
Brezhoneg	6682
Bulgarian	6671
Burmese	7789
Castellano, Español	6983
Catalán	6765
Chamorro	6772
Chechen	6769
Chewa; Chichewa; Nyanja	7889
中文	9072
Chuang; Zhuang	9065
Church Slavic; Slavonic	6785
Chuvash	6786
Corsican	6779
Česky	6783
Dansk	6865
Deutsch	6869
Dzongkha	6890
English	6978
Esperanto	6979
Estonian	6984
Euskara	6985
Ελληνικά	6976
Faroese	7079
Français	7082
Frysk	7089
Fijian	7074
Gaelic; Scottish Gaelic	7168
Gallegan	7176
Georgian	7565
Gikuyu; Kikuyu	7573
Guarani	7178
Gujarati	7185
Hausa	7265
Herero	7290
Hindi	7273
Hiri Motu	7279
Hrwatski	6779
Ido	7379
Interlingua (International)	7365
Interlingue	7365
Inuktitut	7385
Inupiaq	7375
Irish	7165
Íslenska	7383
Italiano	7384
Ivrit	7269
Japanese	7465
Javanese	7486
Kalaallisut	7576
Kannada	7578
Kashmiri	7583
Kazakh	7575
Kernewek	7587
Khmer	7577
Kinyarwanda	8287
Kirghiz	7589
Komi	7586
Korean	7579
Kuanyama; Kwanyama	7574
Kurdish	7585
Lao	7679
Latina	7665
Latvian	7686
Letzeburgesch;	7666
Limburgan; Limburger	7673
Lingala	7678
Lithuanian	7684
Luxembourgish;	7666
Macedonian	7775
Malagasy	7771
Magyar	7285
Malayalam	7776
Maltese	7784
Manx	7186
Maori	7773
Marathi	7782
Marshallese	7772
Moldavian	7779
Mongolian	7778
Nauru	7865
Navaho; Navajo	7886
Ndebele, North	7868
Ndebele, South	7882
Ndonga	7871
Nederlands	7876
Nepali	7869
Norsk	7879
Northern Sami	8369
North Ndebele	7868
Norwegian Nynorsk;	7878
Occitan; Provencal	7967
Old Bulgarian; Old Slavonic	6785
Oriya	7982
Oromo	7977
Ossetian; Ossetic	7983
Pali	8073
Panjabi	8065
Persian	7065
Polski	8076
Português	8084
Pushto	8083
Russian	8285
Quechua	8185
Raeto-Romance	8277
Romanian	8279
Rundi	8278
Samoan	8377
Sango	8371
Sanskrit	8365
Sardinian	8367
Serbian	8382
Shona	8378
Shqip	8381
Sindhi	8368
Sinhalese	8373
Slovensky	8373
Slovenian	8376
Somali	8379
Sotho; Southern	8384
South Ndebele	7882
Sundanese	8385
Suomi	7073
Swahili	8387
Swati	8383
Svenska	8386
Tagalog	8476
Tahitian	8489
Tajik	8471
Tamil	8465
Tatar	8484
Telugu	8469
Thai	8472
Tibetan	6679
Tigrinya	8473
Tonga (Tonga Islands)	8479
Tsonga	8483
Tswana	8478
Türkçe	8482
Turkmen	8475
Twi	8487
Uighur	8571
Ukrainian	8575
Urdu	8582
Uzbek	8590
Vietnamese	8673
Volapuk	8679
Walloon	8765
Welsh	6789
Wolof	8779
Xhosa	8872
Yiddish	8973
Yoruba	8979
Zulu	9085

11 Index

A

amplifier 22
audio
predefined modes 16
specifications 22
audio options 14

C

care
product 3
connectors
front connectors 5
control
disc play 12
main unit 4

D

discs
audio options 14
control buttons 12
options 14
play 12
synchronize picture and sound 12
time search 14
titles 14
display
VCD/SVCD menu 13
display panel 4

F

FM antenna 6

H

HDMI

K

karaoke 16

L

language
language code 27

M

main unit
overview 4
specifications 23
troubleshooting 24
media formats 22
MP3
connector 5

O

options
picture 14
overview
main unit 4
remote control 4

P

picture
options 14
troubleshooting 24
picture options 14
play
discs 12
radio 22
troubleshooting 24
product specifications 22

R

radio
FM antenna 6
specifications 22
tuning grid 15
region codes 22
remote control
batteries 23
overview 4
repeat 14

S

safety
  use of the product 2
sound
  predefined sound mode 16
  surround sound 16
  synchronize picture and sound 12
  troubleshooting 24
sound mode 16
speakers
  specifications 23
  surround sound 16
subwoofer
  specifications 23
synchronize picture and sound 12

T

time search 14
titles 14
trademarks 26
troubleshooting
  connection 24
  main unit 24
  picture 24
  play 24
  sound 24
tuning grid 15

U

USB
  format 22
USB storage device
  options 14
  specifications 22

V

video
  synchronize picture and sound 12
video formats 22
video options 14

WARRANTY

This APPARATUS IS covered under warranty against any defect arising out of faulty or defective material or workmanship for a period of 6 months from date of purchase.

Should a defect develop during the period of warranty, Philips Electronics India Limited undertakes to repair the apparatus free of charge through an Authorised Philips service Center. If the purchaser shifts his residence to other town, the warranty will be valid at the nearest Authorised Philips service Center.

This warranty is not valid in case:
1. The apparatus is not used according to this manual;
2. Defects are caused by improper or reckless use;
3. Any repair work are done by person other than Authorised Philips Service Center;
4. Any modification or alteration of any nature are made in the apparatus;
5. The serial number is tampered
6. This warranty form is not completed immediately after purchase.

Serial No.: _____
Bill No & Date of Purchase: _____
Purchaser's Name: _____
Location & Tel No: _____
Dealer's Name: _____
Location & Tel No: _____
Dealer's Stamp & Sign: _____

Maintenance Tips for your DVD Player:

- Always keep a Disc loaded in your DVD Player tray.
- Keep the player away from the dusty areas. Keep it covered with a dust cover.
- Clean your DVD Player Lens after every 20 discs played.
  - Use the 2 brush Philips DVD Lens Cleaner SVC2520 for best results.
- Clean the CDs / VCD / DVD / MP3 CD before inserting in your DVD Player.

"For unlimited listening pleasure use
Philips earphones / headphones". Over 20 models to choose from

Philips Electronics India Limited

For any sales or service related queries:
Visit us on web at www.philips.com/support or

Call us on Tel No. 1860-180-1111
1800-102-2929
"standard call rates apply"
Email: customercare.india@philips.com



Specifications are subject to change without notice
© 2013 Koninklijke Philips Electronics N.V.
All rights reserved.

HTD5510/5540/5570_94_UM_V1.0