



# AIRDOPES PRIME 413 SMART GUIDE

## PACKAGE CONTENTS



## PRODUCT LABELLING



## POWER ON/OFF




Insta Wake N'Pair (IWP™)

## BLUETOOTH PAIRING



Choose "Airdopes Prime 413" to Connect

## MULTIPOINT CONNECTION



Pair Airdopes Prime 413 with your first media device via Bluetooth.

Turn off the Bluetooth on this device. Switch on the Bluetooth on your second media device to pair with Airdopes Prime 413.

Finally, switch on the Bluetooth of the first media device again.



Congratulations! Your Airdopes Prime 413 is now connected to both the devices successfully.

Note: If the earbuds are not connected, try connecting the first device manually once again to activate multipoint connection.

## FUNCTIONS (CALL/MUSIC)

- Tap Once
- Tap Twice
- L Left Earbud
- R Right Earbud



Note: The earbuds may start at 100% volume level when first switched on. You can adjust the volume to your preferred level using the volume controls on the media device.

## FUNCTIONS (VOICE ASSISTANT / BEAST™ MODE)

- Long Touch (3s)
- R Right Earbud
- L Left Earbud




Note: boAt Signature Sound remains on by default. If the voice assistant doesn't get triggered, then the functionality has to be first enabled via your media device settings. The earbuds may start at 100% volume level when first switched on. You can adjust the volume to your preferred level using the volume controls on the media device.

## HEARABLES APP COMPATIBILITY


Discover the following features of your Airdopes only on the Hearables App:

- ✔ Connectivity and Battery Status
- ✔ Preset & Custom EQs
- ✔ Touch Control Customization
- ✔ Activate/Deactivate Multipoint Connectivity
- ✔ Smart Diagnostics Mode



## RESET AIRDOPES

FORGET DEVICE: 1. Turn on Bluetooth on your device. 2. Press and hold the Reset Button for 10 seconds. 3. Close the lid and wait for a few seconds. Open case & perform a fresh connection.



Note: Red LED blinks 5 times quickly on both earbuds and the charging case to indicate successful reset.

## LED STATUS GUIDE



<30% : 3 RED LED FLASHES	LOW BATTERY
30-70% : BLINKING WHITE LED	CHARGING
>70% : BLINKING GREEN LED	FULLY CHARGED
100% : SOLID GREEN LED	

<30% : RED LED FLASHES 3 TIMES WITH TONE PROMPT	LOW BATTERY
30%-100% : 3 BLUE LED FLASHES	CHARGE

## SPECIFICATIONS

Headphone Type	TWS Earbuds
Bluetooth Version	5.4
Music Playtime	Up to 50 hours (at 60% volume)
Number of AI-ENx™ Equipped Mics	4
IWP™ Tech	Yes
Fast Pair	Yes
BEAST™ Mode	Yes; 60 ms Low Latency
Transmission Range	10 m
Driver Size	12 mm*2
Supported Codec	AAC
Frequency Range	20 Hz-20 kHz
Battery	400 mAh (Case); 35 mAh*2 (Earbuds)
ASAP™ Charge	Yes; 10 mins charge = 150 mins playtime
Charging Time	30 mins (Earbuds); Up to 1.5 hours (Case)
Charging Interface	USB Type-C
Water Resistance	IPX5

Fast Pair: In one tap, Airdopes Prime 413 enables quick, effortless Bluetooth pairing with your Android devices. \*Available on Android 10 & above devices only. Some phones may not support Google and Android are trademarks of Google LLC.

## CHARGING GUIDELINES



Note: (1) Before using the earbuds for the first time, it is recommended to fully charge them. (2) Please note that the earbuds cannot be used / switched on while charging. (3) Any other accessory can be used to charge the product if the above-mentioned norms are followed.

LEARN MORE ABOUT YOUR PRODUCT



Scan this QR Code to Access Your Product's Manual, FAQs, and Warranty Information