

ACWO®



EARBUDS

DWOTS FIRE MAX

Manual



Appearance:

- 1 Glow-Ready Quicksand Case
- 2 Left OWS Earbud
- 3 Right OWS Earbud
- 4 Charging Case
- 5 Left Earbud Charging Socket
- 6 Right Earbud Charging Socket
- 7 Type-C Charging Interface
- 8 Multi-Function Touch Area

What You Will Find In The ACwO Box?

- Charging Case
- Pair of OWS Earbuds
- Scan Me Card

Product Features:

- Open-Ear Wearable Stereo Earbuds
- Glow-Ready Quicksand Case
- Up to 65 Hours of Music Playtime
- AI-ENC Noise Reduction Technology
- Skin-Friendly Ear Hooks for All-Day Comfort
- Enhanced Environmental Awareness
- Single-Press Voice Assistant Activation
- IPX5 Water & Sweat Resistance
- No Hygiene Concerns (Open-Ear Design)
- Bluetooth v5.3 Technology
- 10-Min Charge = 120-Min Playtime
- Instant Auto Connect
- Gaming Ready with Ultra-Low Latency (40ms)

- 15mm Real Drivers with Bass BoomXTM

Safety Guidelines:

- To ensure a safe and enjoyable experience with your OWS Earbuds, please follow these important safety guidelines:

Charging & Battery Safety:

- Use only the provided charging cable or a compatible charger.
- Avoid overcharging; disconnect once fully charged.
- Keep the charging case and earbuds away from water and moisture.
- Do not expose the earbuds or charging case to extreme heat or direct sunlight.

Usage & Hearing Protection:

- Keep the volume at a moderate level to prevent hearing damage.
- Avoid prolonged listening at high volumes to protect your ears.
- Take regular breaks when using earbuds for extended periods.
- Do not use earbuds while driving or in situations requiring full attention.

Handling & Maintenance:

- Store earbuds in the charging case when not in use to prevent loss or damage.
- Clean earbuds regularly using a soft, dry fiber cloth to remove dust and debris.

- Do not attempt to disassemble or repair the earbuds your- self.
- Keep earbuds away from strong magnetic fields or electronic interference.

Water & Sweat Resistance:

- Wipe off sweat or moisture before placing earbuds back in the case.
- Do not submerge the earbuds or expose them to excessive water.

Connectivity & Wireless Safety:

- Keep earbuds within the recommended Bluetooth range for stable connectivity.
- Avoid using earbuds near medical devices, as wireless signals may interfere.
- If experiencing discomfort or irritation, stop using the earbuds immediately.

ACwO DwOTS Fire Max:

Kindly Note:

- Please take off the sticker peels attached below the earbuds before you charge them.
- Charge the charging case and the ACwO DWOTS FIRE MAX Wireless Earbuds at least 70% before the first usage.

Charging:

- **Charging Case:**
Connect the type-c charging cable to the charging case to charge your ACWO DWOTS FIRE MAX Wireless Earbuds.
- **Earbuds:**
Before use remove the blue protective film on the earbuds. Place the earbuds in the charged Charging Case to charge the ACWO DWOTS FIRE MAX Wireless Earbuds.

Bluetooth Pairing Process:

- Take out the ACWO DWOTS FIRE MAX Earbuds from the Charging Case and place them in your ears.
- Go to the Bluetooth settings of your device and switch it on.
- Scan available devices.
- Search For" ACWO DWOTS FIRE MAX" from the list of Pair" ACWO DWOTS FIRE MAX" from the list and your Earbuds will be connected.

Once you've completed the initial pairing process, the ACWO DWOTS FIRE MAX will connect seamlessly to your device every time you open the charging case.

Kindly Note :

If the earbuds are not in use and are left outside the charging case, they will automatically turn off after approximately 5 minutes.

Bluetooth Reset Process: ACWO DWOTS FIRE MAX

- In case your earbuds encounter pairing issues or if only one earbud is functioning, you can easily perform a reset.
- Clear all Bluetooth data named "ACWO DWOTS FIRE MAX" from your device and disable Bluetooth.
- Place the earbuds back into their charging case and then remove them to initiate the Bluetooth pairing process once more.

How Does The Quicksand Case Work?

Glow Effect:

- The quicksand case glows when exposed to UV light.
- You can activate the glow using sunlight, a UV torch, or your phone torch.
- After exposure, the case emits a subtle glow in low-light or dark conditions.

To Experience It:

- Place the case under a light source for a few seconds.
- Move into a darker area to see the glowing quicksand effect come alive.

ACWO DWOTS FIRE MAX - Smart Functions

Play/Pause:

- Single tap on the Multi-Function Touch Area of either earbud.

Next Track:

- Double tap twice on the Multi-Function Touch Area of the right earbud.

Previous Track:

- Double tap twice on the Multi-Function Touch Area of the left earbud.

Increase Volume:

- Triple tap on the Multi-Function Touch Area of the right earbud.

Decrease Volume:

- Triple tap on the Multi-Function Touch Area of the left earbud.

Switch Sound Modes:

- Long press the Multi-Function Touch Area on either earbud for 3 seconds to switch between Rock and Normal Mode.

Voice Assistant Support (OK Google & Hey Siri):

- Tap 4 times the Multi-Function Touch Area on either earbud.

- ### Answer Call:

Single tap on the Multi-Function Touch Area of either earbud.

- ### Hang Up Call:

Double tap on the Multi-Function Touch Area of either earbud.

-

Decline Call:

Long press for 3 seconds on the Multi-Function Touch Area

One need not activate Environmental Noise Cancellation as the built-in mic is already equipped with the same and activated by default to make your conversations smoother and clear without any disturbances no matter how noisy your environment is.