

SONY

Wireless Stereo Headset

Reference Guide

參考指南

참고 설명서

دليل مرجعي


5-060-550-35(1)



©2024 Sony Corporation

Printed in China

https://www.sony.net/



English

Wireless Stereo Headset

Model: YY2982

The term "product" in this document refers to the unit or its accessories.

- This product will generate heat when charging. Always charge in a well ventilated area. Do not charge under pillows, blankets or on flammable surfaces.
- Keep this product away from heat sources, direct sunlight, combustible gas, humidity, water or other liquids.
- Do not disassemble, open, microwave, incinerate, paint or insert foreign objects into this product.
- Do not subject this product to mechanical shock such as crushing, bending, puncturing or shredding. Avoid dropping or placing heavy object on this product.
- Do not short-circuit this product or store it in a receptacle where it may be short-circuited by other metallic or conductive objects.
- Do not operate this product if it has been wet or otherwise damaged, to prevent electric shock, explosion and/or injury. Contact the dealer or

authorised agent for assistance.

- This product usage by children should be supervised.
- Please read this document (including charging instructions and information on the minimum and maximum operating temperatures), supplied with this product.
- Do not dismantle, open or shred secondary cells or batteries.
- Do not expose cells or batteries to heat or fire. Avoid storage in direct sunlight.
- Do not subject cells or batteries to mechanical shock.
- In the event of a cell leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.
- Do not use any charger other than that specifically provided for use with the unit.
- Do not use any cell or battery which is not designed for use with the unit.
- Seek medical advice immediately if a cell or a battery has been swallowed.
- Always purchase the battery recommended by the device manufacturer for the unit.
- Wipe the cell or battery terminals with a clean dry cloth if they become dirty.
- Secondary cells and batteries need to be charged before use. Always use the correct charger and refer to the manufacturer's instructions or product manual for proper charging instructions.
- Do not leave a battery on prolonged charge when not in use.
- After extended periods of storage, it may be necessary to charge and discharge the cells or batteries several times to obtain maximum performance.
- Use only cells or batteries that are appropriate for the intended use.
- Dispose of properly.

Without permission granted by the NCC, no company, enterprise, or user shall change frequency, enhance transmitting power or alter original characteristics as well as performance of approved low power radio-frequency devices. The low power radio-frequency devices shall not influence aircraft security nor interfere with legal communications; If found, the user shall cease operating immediately until no interference is achieved. The said legal communications refers to radio communications operated in compliance with the Telecommunications Management Act. The low power radio-frequency devices must endure interference from legal communications or ISM radio wave radiated devices.

Do not install the product in a confined space, such as a bookcase or built-in cabinet.

Do not expose the batteries (battery pack or batteries installed) to excessive heat, such as sunshine, fire or the like, for a long time. Do not subject the batteries to extreme low temperature conditions that may result in overheating and thermal runaway. Do not dismantle, open, or shred secondary batteries. In the event of a secondary battery leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice. Secondary batteries need to be charged before use. Always refer to the manufacturer’s instructions or product manual for proper charging instructions.

After extended periods of storage, it may be necessary to charge and discharge the secondary batteries several times to obtain maximum performance. Dispose of properly.

Charging this product

Place the headset units into the charging case. Use a commercially available USB Type-C® cable and a USB AC adaptor. Connect the USB AC adaptor to the charging case using the USB Type-C cable, then connect the USB AC adaptor to an AC outlet.

This unit has been tested and found to comply with the limits set out in the EMC regulation using a connection cable shorter than 3 m.

Do not use, store, or leave in a place subject to high amounts of humidity, dust, smoke, or steam, or in a place subject to high temperatures, such as near a fire or a location subject to direct sunlight, such as in a car.

High volume may adversely affect your hearing.

Do not use the unit while walking, driving, or cycling. Doing so may cause traffic accidents.

Do not use in hazardous areas unless the surrounding sound can be heard.

If water or foreign matter enters the unit, it may result in fire or electric shock. If water or foreign matter enters the unit, stop use immediately and consult your nearest Sony dealer. In particular, be careful in the following cases.

- When using the unit near a sink or liquid container
 - Be careful that the unit does not fall into a sink or container filled with water.
- When using the unit in the rain or snow, or in humid locations

For details on the effects of contact with the human body from the mobile phone or other wireless devices connected to the unit, refer to the

instruction manual of the wireless device.

If the earbud tips are not securely attached, they may fall off and remain inside the ear during use. Make sure that the earbud tips are securely attached before use.

Never insert the USB plug when the unit or charging cable is wet. If the USB plug is inserted while the unit or charging cable is wet, a short circuit may occur due to liquid (tap water, seawater, soft drink, etc.) or foreign matter on the unit or charging cable, and cause abnormal heat generation or malfunction.

This product has magnet(s) which may interfere with pacemakers, programmable shunt valves for hydrocephalus treatment, or other medical devices. Do not place this product close to persons who use such medical devices. Consult your doctor before using this product if you use any such medical device.

This product has magnet(s). Swallowing magnet(s) could cause serious harm, such as choking hazard or intestinal injuries. If magnets (or a magnet) were swallowed, consult a doctor immediately. Keep this product away from children or other supervised individuals to prevent accidental ingestion.

There is a danger that this unit or its small parts may be swallowed. After use, store the unit in the charging case and store in a location out of reach of small children.

Note about static electricity

If you use the unit when the air is dry, you may experience discomfort due to static electricity accumulated on your body. This is not a malfunction of the unit. You can reduce the effect by wearing clothes made of natural materials that do not easily generate static electricity.



Precautions

The two-dimensional code or the URL on the cover will help you access the help guide that describes useful notes or procedures in details.

<p>On water resistant of the unit</p> <ul style="list-style-type: none">The charging case is not water resistant. Unless the unit is used correctly, water may get into the unit and cause fire, electrocution, or malfunctions. Note the following cautions carefully and use the unit correctly. <p>To maintain water resistant performance</p> <p>Carefully note the precautions below to ensure proper use of the unit.</p> <ul style="list-style-type: none">Do not splash water forcibly into the sound output holes. Do not drop the unit into water, and do not use underwater. Do not allow the unit to remain wet in a cold environment, as the water may freeze. To prevent malfunction, make sure to wipe off any water after use. Do not place the unit in water or use it in a humid place such as a bathroom. Do not drop the unit or expose it to mechanical shock. Doing so may deform or damage the unit, resulting in deterioration of water resistance performance.
--

On BLUETOOTH® communications

- Microwaves emitting from a Bluetooth device may affect the operation of electronic medical devices. Turn off this unit and other Bluetooth devices in the following locations, as it may cause an accident:
 - in hospitals, near priority seating in trains, locations where inflammable gas is present, near automatic doors, or near fire alarms.

Notes on wearing the unit

- Because the earbud tips achieve a tight seal in the ears, forcibly pressing them in or quickly pulling them out can result in eardrum damage. When wearing the earbud tips, the speaker diaphragm may produce a click sound. This is not a malfunction.

Other notes

- If you experience discomfort while using the unit, stop using it immediately.
- If you have any questions or problems concerning this unit that are not covered in this manual, please consult your nearest Sony dealer.
- 兒童應在監督下使用本產品。

Specifications

Headset

Power source:

- DC 5 V (Using a commercially available USB AC Adaptor)
- Using built-in lithium-ion batteries (Product Operation Power: DC 3.85 V)

Operating temperature:

- 0 °C to 40 °C

Mass:

- Approx. 4.6 g × 2 (Headset (including earbud tips (M)))
- Approx. 31 g (Charging case)

Included items:

- Wireless Stereo Headset (1)
- Hybrid silicone rubber earbud tips (SS (2), M (2), LL (2))
- Charging case (1)
- Documents (1 set)

Communication specification

Communication system:

- Bluetooth Specification version 5.3

Output:

- Bluetooth Specification Power Class 1

Frequency band:

- Bluetooth: 2.4 GHz band (2.400 0 GHz - 2.483 5 GHz)

Design and specifications are subject to change without notice.

System requirements for battery charge using USB

USB AC adaptor:
A commercially available USB AC adaptor capable of supplying an output current of 0.5 A (500 mA) or more.

USB cable:
Commercially available USB Type-C® cable (compliant with USB standards)

<p>Trademarks</p> <ul style="list-style-type: none">The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Group Corporation and its subsidiaries is under license. USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum. All other trademarks and registered trademarks are trademarks or registered trademarks of their respective holders. In this manual, ™ and ® marks are not specified.
--

Licenses

- This product contains software that Sony uses under a licensing agreement with the owner of its copyright. We are obligated to announce the contents of the agreement to customers under requirement by the owner of copyright for the software. Please access the following URL and read the contents of the license. https://rd1.sony.net/help/mdr/sl/24/
- Services offered by third parties may be changed, suspended, or terminated without prior notice. Sony does not bear any responsibility in these sorts of situations.

繁體中文

無線立體聲耳機

型號: YY2982

本文件中的用語“產品”是指裝置或其配件。

- 本產品充電時會發熱。務必在通風良好的區域充電。請勿在枕頭、毛毯或易燃表面下充電。
- 本產品必須遠離熱源。直射陽光、可燃氣體、濕氣、水或其他液體。
- 請勿拆解、開啟、微波加熱、焚燒、油漆或將異物插入本產品。
- 請勿使本產品受到機械衝擊，例如壓碎、彎曲、刺穿或切碎。避免掉落或放置重物在本產品上面。
- 請勿造成本產品短路或將其貯放在可能由於其他金屬或導電物體而短路的容器中。
- 如果本產品受潮或遭受其他損壞，請勿使用，以免造成觸電、爆炸和/或人身傷害。請聯絡經銷商或授權代理商獲取幫助。
- 兒童應在監督下使用本產品。

- 請閱讀本產品隨附的本文件（包括充電說明，以及最低和最高操作溫度的資訊）。
- 不得拆解、開啟或撕裂二次單電池或電池組。
- 不得使單電池或電池組曝露於熱或火源。避免存放在陽光直射處。
- 不得使單電池或電池組接受機械性衝擊。
- 當單電池發生洩漏時，不得使液態電解質接觸皮膚或眼睛。若不慎接觸時，以大量清水沖洗患部並尋求醫療協助。
- 不得使用任何非指定搭配設備使用之充電器。
- 不得使用任何非設計搭配設備使用之單電池或電池組。
- 若不慎吞食單電池或電池組時，應立即尋求醫療協助。
- 務必選購由設備製造商建議使用之電池組。
- 當單電池或電池組之端子不潔時，以清潔之乾布擦拭。
- 二次單電池及電池組需於使用前充電。務必使用正確之充電器並依電池製造商所提供之說明書或設備之使用手冊，以正確之程序進行充電。
- 當不使用時，勿使電池組長時間處於充電狀態。
- 經長時間存放後，可能需對單電池或電池組進行數次充、放電，以達其最大效能。
- 僅使用適用於預期用途之單電池或電池組。
- 棄置時應妥善處理。

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前述合法通信，指依電信管理法規定位業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

請勿將本產品安裝於密閉的空間內，例如書架或內建的櫥櫃內。

請勿將電池（電池組或已安裝的電池）長時間曝露於過熱的環境，例如陽光、火源等等。請勿使通用電池處於極端低溫條件下，否則可能導致過熱和熱失控。請勿拆卸、打開或切碎充電式電池。如果充電式電池漏液，請勿讓液體接觸皮膚或眼睛。如果已經接觸，請用大量清水沖洗患部並就醫。使用前需要對充電式電池充電。請務必參閱製造商說明或產品手冊的正確充電說明。長時間存放後，可能需要對充電式電池多次充電和放電，才能達到最佳效能。妥善處置。

為本產品充電
將耳機裝置放入充電盒中。使用市售的USB Type-C®連接線和USB AC變壓器。使用USB Type-C連接線將USB AC變壓器連接到充電盒，然後將USB AC變壓器連接到AC插座。

經測試，本裝置符合EMC規定中使用3 m以下連接線的限制。

請勿在有大量濕氣、粉塵、煙塵或蒸氣的場所使用、儲存或放置在上述地點，或者放置在高溫場所，例如接近火源處或陽光直射處，例如車內。

高音量可能會對您的聽力產生不良影響。

在走路、駕駛或騎單車時，請勿使用本裝置。否則可能發生交通意外。

除非可以聽到周圍的聲音，否則請勿在有危險性的區域使用本裝置。

- 如果水或異物進入本裝置，可能發生火災或電擊。如果水或異物進入本裝置，請立即停止使用，並詢問鄰近的Sony經銷商。請特別小心下列情況。
- 在水槽或液體容器附近使用本裝置時
 - 請小心勿使本裝置掉入裝有水的水槽或容器中。
- 在雨中或雪中使用，或在潮濕的地方使用時

關於連接本裝置的行動電話或其他無線裝置接觸到人體所產生的影響，請參閱無線裝置的說明手冊。

如果耳塞未牢固安裝，則在使用過程中可能會掉落並留在耳內。使用前，請確認已牢固安裝耳塞。

當本機或充電線潮濕時，切勿插入USB插頭。如果在本機或充電線潮濕的狀況下插入USB插頭，可能會因本機或充電線上黏附的液體（自來水、海水、汽水等）或因異物而造成短路，並導致異常發熱或故障。

本產品有磁力，可能會干擾心律調節器、用於腦積水治療的可調式引流閥或其他醫療器材。請勿將本產品放在此類醫療器材使用者的附近。如果您使用任何此類醫療器材，請在使用本產品前諮詢您的醫生。

本產品有磁力。吞嚥磁鐵可能造成嚴重傷害，例如窒息危險或腸道損傷。如果吞下磁鐵，請立即就醫。請將本產品放在遠離兒童或其他受監護者的地方，以防誤食。

本裝置或其細小零件有遭到吞食的危險。使用本裝置後請將其存放在充電盒內，並放在兒童無法觸及之處。

關於靜電的附註

如果在空氣乾燥的情況下使用本裝置，由於人體積聚靜電，您可能會感到不適。這並非本裝置故障。您可以穿著不易產生靜電的天然材質製成的衣服來降低這種效果。

僅適用於台灣

廢電池請回收

設備名稱：無線立體聲耳機，型號（型式）：YY2982						
單元	限用物質及其化學符號					
	鉛 (Pb)	汞 (Hg)	鎘 (Cd)	六價鉻 (Cr ⁺)	多溴聯苯 (PBB)	多溴二苯醚 (PBDE)
電路板	-	○	○	○	○	○
外殼	-	○	○	○	○	○
連接端子	-	○	○	○	○	○
配件（充電盒等）	-	○	○	○	○	○
備考1. “○”係指該項限用物質之百分比含量未超出百分比含量基準值。						
備考2. “-”係指該項限用物質為排除項目。						

台灣索尼股份有限公司

台北市中山北路二段42號5樓

IPX4：無線立體聲耳機

預防措施

封面上的二維碼或URL可幫助您存取有詳細介紹注意事項或操作程序的說明指南。

<p>關於本機的防水滴或噴濺</p> <ul style="list-style-type: none">充電盒並不防水滴或噴濺。 除非正確使用，否則本機可能進水，造成起火、觸電或故障。請注意以下注意事項，並正確使用本機。 <p>若要保持防水滴或噴濺性能</p> <p>請小心注意下列預防措施，以確保正確使用本機。</p> <ul style="list-style-type: none">請勿朝聲音輸出孔用力潑水。 請勿使本機掉入水中，而且請勿在水中使用。 請勿在寒冷的地方讓本機持續潮濕，否則水可能會結冰。為了防止故障，使用後請確認將任何水擦乾。 請勿將本機放在水中或在浴室等潮濕場所中使用。 請勿使本機掉落或受到機械衝擊。這樣可能會使本機變形或受損，導致防水滴或噴濺性能變差。

關於BLUETOOTH®通訊

- Bluetooth裝置所放射的微波可能影響電子醫療裝置的運作。為免發生意外，在下列位置請關閉本機和其他Bluetooth裝置：
 - 在醫院內、火車內的博愛座附近。有可燃性氣體的其他地點、自動門或火災警報器附近。

配戴本機的注意事項

- 因為耳塞在耳朵內形成密封狀態，如果將它們用力壓入，或快速將它們拉出，可能會損傷耳膜。

戴耳塞時，揚聲器膜片可能會發出喀咯聲。這並不是故障。

其他注意事項

- 如果您在使用本機後發生不適，請立即停止使用本機。
- 如果您有任何關於本機的疑問或問題而本說明書中並未提及，請洽詢鄰近的Sony經銷商。

規格

<p>耳機</p>
<p>電源：</p> <ul style="list-style-type: none">DC 5 V（使用市售USB交流電源供應器） 使用內置鋰離子電池（產品操作電源：DC 3.85 V）

