

Congratulations and Willkommen! You are now part of the Blaupunkt

You have chosen German iconic brands premium earbuds and have become a part of an elite group that enjoys and appreciates the finest audio experience.


To get the best performance from your Blaupunkt audio product please read this manual carefully and follow the instructions. This will ensure you get the most out of your Blaupunkt product. Keep the manual safely

refer to it when in doubt.

CAN!

One OR Code to access everything - Warranty, Blue Points. Manuals, Service and all you will ever need.

Product Description:



- 1. Ear Muffs
- 2. Ear Support

- 3. Metal Cavity 4. Auricular Line

- 7. Type-C
- 5. Head Arch Line 6. LED
- 8. Multi Functional Touch Key
- . Charging Mode: Indicator light is steady red Fully Charged Mode: The indicator light is steady blue

Basic Operation:

blue with a prompt sound.

connected successful.

Charge Indicator:

· Power On: Separate the left and right earphone magnets, the

blue light flashes once, and then alternates between red and

Power Off: Close the left and right ear magnets, the red light

• Pairing Mode: After power on, it automatically enters the pairing

mode, and the indicator lights alternately red and blue. (If the

for the mobile phone in the working range after the power is

turned on, and then connect back to the mobile phone.)

the connection is accompanied by a prompt voice when

mobile phone has been connected, it will automatically search

• Connect the Mobile Phone: After the headset enters the pairing

mode, open the mobile phone Bluetooth, search for the device.

click the device with the matching name "BLAUPUNKT BE", and

flashes once and goes out, and there is a prompt sound.

Playing Music Operation:

- Play/Pause: Open the music player and touch the multifunction button once.
- Previous Song: Open the music player and briefly press the touch button twice.
- Next Song: Open the music player on your phone and briefly press the touch button 3 times.
- Game Mode: Press and hold the touch button for 2 seconds to enter game mode.
- Music Mode: Press and hold the touch button for 2 seconds to enter music mode.

Call Operation:

- Incoming Call Answering: When a call comes, touch the
- multifunction button. Reject Incoming Calls: When making a call, press and hold the
- touch button for 2 seconds. • End Call: During the call, touch the multifunction button.

Safe Use Specification:

- · Do not disassemble or modify the headphones for any reason. Otherwise, the headphones may malfunction or burn out. These are not covered by the warranty.
- Do not immerse the headphones in the liquid, otherwise the headphones will be seriously damaged.
- Do not use the headphones in an environment where the temperature is too low or too high (below 0 degrees or above 45 degree).
- · Please avoid the child or animal's eyes close to the indicator light of headphones.
- Do not use headphones in thunderstorms. Thunderstorms may Email- wecare@blaupunktaudio.in cause the headphones to work abnormally and increase the risk Whatsapp Chat Support: 8860 022 600 of electric shock.

Please submit the following information while claiming product warranty:

Khasra, No- 15/15(4-16), Village Samalkha, Tehsil Vasant Vihar, New Delhi-

Please be careful while listening to music, Blaupunkt has always ensured

If you have any issue with your product please contact our Authorized

that every audio product is powerful and produces massive bass and other

audio ranges. Please raise the volume levels slowly and do not play music at

ATTENTION

1 Year Warranty

Customer Care team.

Envent World Wide Pvt Ltd.

- -Serial Number
- -Date of purchase -A copy of proof of purchase in case of warranty

full volume levels as this could hurt your ears.

Blaupunkt Authorized Service Center:

Note- If you do return the product, please use the original packaging or other suitable packaging to protect it in transit.