

ROCKID RUSH




Thank you for choosing the boAt Rockid Rush. This manual is meant to guide you through to the shores of musical bliss without much difficulty. Please think of this manual as your map. Knowledge of Bluetooth and device connection is essential for steering this boAt. Therefore, we strongly advise that this manual is thoroughly read before use and referred to in times of difficulty.

Package Contents:

- boAt Rockid Rush
- User Manual
- USB Type C Charging Cable
- Warranty Card
- Sticker Card
- Catalogue

Product Overview:



Power On: Set the power toggle switch to ON state, the headset has a power-on prompt tone.

Power Off: Set the power toggle switch to OFF state.

Bluetooth Connectivity

1. Turn on the Bluetooth functionality on your phone and switch on Rockid Rush by setting the toggle power switch to on state.
2. Then, click on the headphones 'Rockid Rush' from the list of available devices after search
3. If asked for a passkey, confirm the passkey '0000' on phone
4. Once confirmed, the headphone and phone get connected via Bluetooth indicated by slowly flashing blue LED

5. To disconnect the current paired device and enter pairing mode, long press the MFB for 10 seconds.

Note: If there's a connection history between the phone and the headphone, then they will automatically get reconnected in a working range whenever the headphone gets switched on.

Safe & Sound

This headphone comes with an audio limiter of up to 85dB, thereby offering a safe listening experience for our cute-super heroes.

Basic Functions :

Play	Short press the MFB once to play
Pause	Short press the MFB once to pause
Answer Incoming Calls	Short press the MFB once
Hang Up Ongoing Calls	Short press the MFB once
Reject Calls	Press and hold the MFB for one second
Switch Call between Headphone & Phone	Press & hold MFB for 1 second
Voice Assistant/Siri	Double press the MFB

Note:

If the voice assistant doesn't get triggered, then the functionality has to be first enabled via your media device settings.

Charging

- Connect one end of the provided cable to the USB Type C port on the headset and the other end to a wall adapter or laptop
- While charging the indicator LED turns into steady red
- When the headphone is fully charged, the indicator switches off
- Use only authorized/company chargers for the headset, as unauthorized ones may damage the same and invalidate the warranty on the headset as well
- The headphones cannot be utilized for listening purposes while it is in charging mode

Note: When the headphones are in low power state, then that gets indicated by slowly flashing red LED.

ENx™ Tech

Our ENx™ tech algorithm cancels out the background noise so that you can be heard crystal clear via voice calls. One need not activate ENx™ as the mic is equipped with the same and activated by default. **Deliver your voice without interruptions anywhere - traffic, railway stations, airports, playground, gaming zones; literally anywhere!**

Other Functions :

- If there's no connection established when the Bluetooth is switched on, then the device powers off automatically after a while
- If you receive an incoming call during playing music, the music automatically disconnects. When the call is done and disconnected, the music starts to play automatically from where it left

ANOMALIES & Solutions

A. Mobile can't search the headset

- Check if the Bluetooth headset is powered on or off. (When powered on, the LEDs blink with red and blue colours alternatively)
- If it is powered on and the device still can't connect, then please reboot the Bluetooth device and the phone

B. After connecting the headset with the phone, disconnection or noise occurs

- This may be due to the low power of the headset. Please charge the Bluetooth headset
- There might be obstruction between the headset and the phone or the distance between them exceeds the maximum range for signal reception

C. If the Voice Assistant support doesn't respond

- If the voice assistant doesn't get triggered, then the functionality has to be first enabled via your media device's settings.

Specifications :

Headphone Type	Bluetooth Headphones for Kids
Driver Size	30mm*2
HD Sound	Yes
Frequency Range	20HZ-20KHZ
Bluetooth Version	V5.3
Bluetooth Profile	HSP, HFP, A2DP, AVRCP
Bluetooth Range	10m
Battery Capacity	300mAh
Playing Time	Up to 10 Hours (At 60% vol approx.)
Charging Time	2 hours
Standby Time	300HRS
Charge Interface	USB Type C
Sound Limiter	Yes, 85dB
Charging Voltage	5V/2A
Charge Interface	USB Type C

Safety Precautions:

- This is not a toy. The children are advised to use this under adult supervision.
- Avoid using this device for more than one hour on a stretch.
- Avoid exposing the device to extremely hot or cold temperatures or even normal damp conditions.
- Avoid using the headphone for listening to full volumes to protect from hearing damage.
- Please do not use the device under thunderstorms.
- Don't dismantle the product in any way.
- Please don't clean the product using oily volatile liquid

