

Manual


Thank you for purchasing boAt Stone Lumos. You are now just a step away from the realm of pure audio bliss.

Please follow this user manual carefully in case of any doubts and difficulties that arise. Please note that playtime will vary depending on the selected volume level. You can stay plugged into the sound via Bluetooth wireless technology, USB, and AUX wire compatibility. This portable wireless speaker has been designed with a smooth interface that requires minimum efforts.

PACKAGE CONTENTS

- 1 x boAt Stone Lumos
- 1 x User Manual
- 1 x USB Type-C charging Cable
- 1 x AUX Cable

PRODUCT OVERVIEW:



BASIC FUNCTIONS:

1. Previous Track/Volume Down
2. Next Track/Volume Up
3. Play/Pause
4. EQ Button/Switch Mode (Bluetooth/USB/AUX)
5. Projection Light Button
6. TWS Button
7. Power On/Off
8. USB Port
9. Type-C Charging Jack
10. AUX Port

FEATURES:

- Amazing projection lamp combined with music to amp up your audio space
- boAt Hearables app compatibility to customize light projection and switch EQ modes
- TWS function to experience True Stereo Sound
- Bluetooth v5.3 for faster and stable wireless connectivity
- Supports USB flash disk and AUX-IN
- Built-in hands-free mic for attending phone calls
- Sturdy aluminium handle for hassle-free portability

POWER ON/OFF:

Long press the Power button to turn the speaker on and off.

BLUETOOTH PAIRING:

- Press the power button to switch on the speaker. The speaker enters Bluetooth pairing mode automatically.
- Activate the Bluetooth on your smartphone and search for "Stone Lumos" to connect.
- Once paired, you can start playing music from your smartphone and enjoy. Note: If your smartphone is disconnected from the speaker due to shut down or switching the mode, the speaker will automatically reconnect to your smartphone when it is turned on again or switch back to Bluetooth mode.

BASIC FUNCTIONS & PORTS

Play/Pause	Short press the Play/Pause button to play or pause a track.
Previous Track	Long press the button to go to the previous track.
Next Track	Long press the button to go to the next track.
Volume Up	Short press the button in steps to increase the volume.
Volume Down	Short press the button in steps to reduce the volume to your desired level.
Projection Light Button	Short press the button to turn on Projection light and switch between different projection colors (7 colors in total). Long press the button to turn off Projection light.

EQ Button	Short press the EQ button to switch between two different EQ modes. Long press the EQ button to switch the connectivity mode (Bluetooth/USB/AUX).
TWS Button	Long press the TWS button for 2 seconds to disconnect the mobile phone from the speaker.
AUX Port	Insert the AUX cable here
Type-C Charging Port	Insert the Type-C charging cable over here
USB Port	Insert the USB flash drive in this slot

OPERATING INSTRUCTIONS

TWS FUNCTION:

- Turn on the two Stone Lumos speakers that you require to be forged into one, both in Bluetooth mode. You only need to set one of the two units and follow the steps below-
- Short press the TWS button to pair. The white TWS LED indicator will keep blinking after successful pairing. The white LED indicator will turn off after 1 minute if pairing fails.
 - Enable Bluetooth connection with your mobile phone to play music through the two paired speakers.
 - Short press the TWS button again to exit TWS function.

USB MODE:

- Press the power button to switch on the speaker.
- Insert the USB flash drive into the USB port. The speaker will play the stored music automatically.

Front

WARNING:

- Please store and use this product in an environment with normal temperature.
- Please do not expose this product to rain or moisture.
- Please do not disassemble, repair or modify this product by yourself without authorization.
- When cleaning this product, please use a soft or damp cloth, please do not use chemicals for cleaning.
- In order to have an extended product life and protect your hearing, please avoid listening to songs on maximum volume for long time.
- The product has a built-in lithium battery. To avoid danger, please do not discard or put it in the fire.

Back

SPECIFICATIONS

Bluetooth Version	5.3
Dimension	370*(L)*164.6(H)*106(W) (in mm)
Weight	2 kg
Working Range	10m
Driver Size	2.75 inch*2
Compatibility	BT/AUX/USB
Frequency	80HZ-16KHZ
Input Voltage	7.4 V
Output Power	60W
Charging Time	Up to 4.5 hours
Playing Time	Up to 9 hours (*LED Projection Light Off & @60% volume)
Battery	4400mAh @7.4V
Water Resistance	IPX4

REMARKS :

- The default volume is at 50% of the maximum volume level.
- Playtime may vary depending on the volume level and type of music.

RESET FUNCTIONALITY:

Perform the Reset function if the speaker doesn't turn off or doesn't respond properly.
 Step 1: Use a small round pin to short press the bottom of the AUX port to reset the speaker.
 Step 2: Long press the TWS button for 5 seconds; the speaker will turn off and clear the Bluetooth connection memory.

AUTO POWER OFF :

- To save power and prevent the battery from running out, the speaker will auto power off in any of the cases mentioned below-
- In Bluetooth mode, if the speaker is not connected to the mobile phone in 30 minutes.
 - In Bluetooth mode if the speaker is connected to the mobile phone, but no music is played for 30 minutes.
 - In USB mode if the music is paused for 30 minutes.
 - In AUX mode if the music is paused for 30 minutes.


HOW TO CHARGE:

- When the battery is low, the speaker will make a prompt sound, and the pink LED indicator will start to blink.
 - The charger is not included in the package. Please charge this speaker via a 5V/2A charger or via PC. A Fast charger rated 9V/2A is supported as well.
 - After inserting the charging cable when the speaker is in charging mode, the pink LED indicator (it is red LED indicator if the speaker is off) stay on.
 - Once the charging gets completed, the LED indicator turns off (the device will fully recharge in about 3 to 4.5 hours).
- Note:
- Please don't use the speaker while it is charging, as this may decrease the battery's performance.
 - If the battery is completely discharged, the speaker may restart. Leave it in off state and charge it for at least an hour before using it.

boAt HEARABLES APP FUNCTIONALITIES

Switch EQ Mode	Under the "Sound" tab on the app, go to the Equalizer header and select 'Balanced' or 'Deep Bass' EQ mode. Balanced mode remains activated by default.
Control Light Show	In the "System" tab, the 'Light Show' header lists the light projection options. This function remains off by default. Slide the toggle to the "ON" state to activate. -Colors: Choose from 7 different color modes by tapping the color spheres as per your liking. -Stars: Use this option to project stars in combination with the colored light. Select 'Static' mode to keep the star effect stationary and 'Rhythm' mode to view the stars in motion. Tap 'Off' to turn off the star projection.

Scan the QR code and download the boAt Hearables app for an elevated experience.



Note:
 -In any playing mode, when you insert a USB disk into the speaker, it will switch to play the USB disk.
 -If you use a USB extension cable, the connected storage device may not be recognized or function properly.

AUX MODE:

- Insert one end of the AUX cable to the AUX input of the speaker and connect the other end to the external device.
- Short press the Play/Pause button to mute the speaker while playing music under AUX mode.

Note:
 -In AUX mode it is necessary to carry out the operation directly from the connected external device.
 -Under any playing mode, when you use the audio cable to connect the device, it will auto-switch to the AUX mode.

ACTIVATING VOICE ASSISTANT:

- Connect the speaker to your mobile via Bluetooth.
- Long press the Play/Pause button to activate the default smart voice assistant and give your commands.

HANDS-FREE CALLING:

- Under Bluetooth connection status, if there is an incoming call, short press the play/pause button to accept the call and long press the play/pause button to reject the call.
- When the call is in progress, long press the play/pause button to switch talking between the mobile phone and the speaker.
- Short press the play/pause button or use the mobile phone to end an ongoing call.