


ACWOW®



mini soundbar

CARNIVAL 414

Manual



Buttons:

- Short press "M": Change EQ modes, Bluetooth, FM, USB, TF, AUX.
- "+": Volume up/Next track
- "-": Volume down/Previous track
- "▶||": Play/Pause, Answer/Hang up phone call, TWS
- "☀": Press to toggle and switch off color modes

Function:

● Bluetooth connection:

When turning on the bluetooth speaker, it will be in bluetooth mode at first. Opening your bluetooth device and searching for "ACwO CARNlwAL 414" to connect . Once this speaker is paired to your device, it will connect to your device automatically next time, if you do not delete the bluetooth memory on your device.

For TV:

1. Turn on your TV and Soundbar

Ensure both devices are powered on.

2. Enable Bluetooth on the TV

Go to your TV's settings, find the Bluetooth section, and make sure it's enabled.

3. Pair the Soundbar

On the ACwO soundbar, press the Bluetooth pairing button (usually marked with a Bluetooth symbol). The soundbar will enter pairing mode.

4. Select the Soundbar on TV

On your TV, navigate to the Bluetooth settings and select ACwO soundbar from the list of available devices.

5. Confirm the Connection

Once connected, you should hear the soundbar emit a sound or notification, indicating the connection is successful.

For Smartphone:

1. Turn on Your Smartphone and Bluetooth

Ensure both your smartphone and Bluetooth device are powered on.

2. Enable Bluetooth on Your Smartphone

Open your phone's settings, go to the Bluetooth section, and make sure Bluetooth is enabled.

3. Pair the Bluetooth Device

On the ACwO soundbar, press the Bluetooth pairing button (usually marked with a Bluetooth symbol). The soundbar will enter pairing mode.

4. Select the Device on Your Smartphone

On your smartphone, navigate to the Bluetooth settings and select ACwO Soundbar from the list of available devices.

5. Confirm the Connection

Once connected, you should hear the soundbar emit a sound or notification, indicating the connection is successful.

For Laptop:

1. Turn on Your Laptop and Bluetooth Device

Ensure both your laptop and Bluetooth device are powered on.

2. Enable Bluetooth on Your Laptop

Go to your laptop's settings, find the Bluetooth section, and make sure Bluetooth is turned on.

3. Pair the Bluetooth Device

On the ACwO soundbar, press the Bluetooth pairing button (usually marked with a Bluetooth symbol). The soundbar will enter pairing mode.

4. Select the Device on Your Laptop

On your laptop, open the Bluetooth settings and select select ACwO Soundbar from the list of available devices.

5. Confirm the Connection

Once connected, you should hear the soundbar emit a sound or notification, indicating the connection is successful.

● Music Play:

Insert USB drive or micro-SD card with MP3 files to enjoy music.

Use the 3.5mm audio cable to connect your phone with the speaker to play music.

Short press "+" to play the next song.

Long press "+" to increase the volume.

Short press "-" to play the previous song.

Long press "-" to reduce the volume.

● Radio Mode:

Insert the charging cable or aux cable into the slot to act as an external antenna to enhance the signal. Press the "M" button to enter FM mode. Long press the "▶||" button to search channels automatically. After the searching is completed, press +/- to switch the radio.

Plug in the Cable

1. Use a charging or AUX cable to act as an antenna, and connect it to the soundbar slot.

2. Switch to FM Mode

Press the "M" button to turn the soundbar to FM radio mode.

3. Place the Soundbar in a Good Spot

Put the soundbar near a window or in an open area to help it pick up radio signals.

4. Wait for Channels to Load

Give it about 5-10 minutes to automatically detect available radio channels.

5. Search for Channels

Long Press the "Play" button for a few seconds to start automatic channel scanning.

6. Switch Between Channels

Use the "+" or "-" buttons to switch through the available radio channels.

● Audio Mode Selection:

Press and hold the 'M' button for 2 seconds to switch between the available sound modes: Rock, Pop, Classic, Jazz, and Normal. Enjoy tailored audio performance for every mood and moment

How to Connect Two CARNIwAL Soundbars:

1. Power On: Switch on both CARNIwAL soundbars.

2. Pair the Soundbars Together :Press and hold the Play/Pause button on one of the soundbars for 5 seconds. The two soundbars will automatically pair and connect with each other.

3. Connect to Your Device : Using Bluetooth, connect the soundbar to your phone, tablet, or other device.

4. Enjoy Synchronized Sound: That's it! Both soundbars will now play the same audio together, delivering a powerful, immersive sound experience.

- **Charging:**

1. Type-C charging cable.

2. When speaker is charging, the red light will be on, light will be off when it's fully charged.

3. Repeat charging and discharging will lead to the decline of battery life, which is a normal phenomenon for all possible rechargeable batteries.

- **Calling:**

Click the "▶||" button to answer/hang up the phone call, Long press the "▶||" button to reject the phone call.

- **Notice:**

1. Use the product for its intended purpose only.

2. Pls store and use this product at room temperature.

3. Do not expose this product to rain or wet conditions.

4. Do not drop the product to avoid damage from falls.

5. Do not disassemble and repair the product by yourself.

6. The product contains a built-in lithium battery. Do not dispose of it casually or throw it into fire, as it may cause danger.

ACWO® x Sunil Chhetri

**THE LEGEND
OF INDIAN
FOOTBALL TEAM**

