



<div data-bbox="141 158 732 267"><p>pTron</p></div> <div data-bbox="141 267 732 780"><p>Bassbuds Pixel True Wireless Stereo Earbuds</p></div> <div data-bbox="141 780 732 891"><p>User Manual</p></div>	<div data-bbox="732 158 1334 191"><p>Control Button Description:</p></div> <div data-bbox="732 191 1334 616"><p>Touch Sensitive Area (TSA)</p></div> <div data-bbox="732 616 1334 891"><p>Smart Power On & Pairing:</p><ol style="list-style-type: none">1. Open the charging case Or Touch TSA on both the earbuds for 3 seconds.2. Wait for 2-3 seconds until L & R earbuds pair to each other.3. Turn on the Bluetooth on your phone & search "pTron TWS" to connect with the device.</div>	<div data-bbox="1334 158 1937 191"><p>Movie & Gaming Mode:</p></div> <div data-bbox="1334 191 1937 300"><p>Touch TSA for 4 times quickly on either earbud to turn ON the Movie & Gaming mode. Note: Default mode is Movie & Gaming mode off.</p></div> <div data-bbox="1334 300 1937 409"><p>Smart Power Off: Touch TSA on both the earbuds for 3 seconds Or Keep both the earbuds into the charging case.</p></div> <div data-bbox="1334 409 1937 485"><p>Note: TSA stands for Touch Sensitive Area</p></div> <div data-bbox="1334 485 1937 616"><p>Connectivity Bluetooth - Automatic: Just turn on the Bluetooth earbuds. They will automatically connect to the last connected device (Instant wake & pair technology).</p></div> <div data-bbox="1334 616 1937 769"><p>Calling or Music through Mono & Dual Buds: Mono Bud Use - Just place the right or left earbud back into the charging case Dual Buds Use - Use left & right earbuds together.</p></div> <div data-bbox="1334 769 1937 891"><p>Voice Assistant Activation: Touch TSA on either earbud for 2 seconds.</p></div>	<div data-bbox="1937 158 2539 191"><p>Call & Music Functions:</p></div> <div data-bbox="1937 191 2539 278"><p>Answer/Hangup a Phone Call - Touch TSA on either earbud once.</p></div> <div data-bbox="1937 278 2539 333"><p>Reject a Phone Call - Touch TSA on either earbud for 2 seconds.</p></div> <div data-bbox="1937 333 2539 365"><p>Music Play/Pause - Touch TSA on either earbud once.</p></div> <div data-bbox="1937 365 2539 398"><p>Next Song - Touch TSA on either earbud twice.</p></div> <div data-bbox="1937 398 2539 453"><p>Previous Song - Touch TSA on either earbud thrice quickly.</p></div> <div data-bbox="1937 453 2539 518"><p>Note: TSA stands for Touch Sensitive Area.</p></div> <div data-bbox="1937 518 2539 551"><p>Charging the Earbuds:</p></div> <div data-bbox="1937 551 2539 660"><p>1. Place both the earbuds into the charging case properly. The earbuds will power off automatically when placed into the case.</p></div> <div data-bbox="1937 660 2539 758"><p>2. Earbuds LED will start glowing white, which means it is on charging. After full charge earbuds LED light will stop blinking.</p></div> <div data-bbox="1937 758 2539 857"><p>3. Charging case LED light will be blue during charging the earbuds. It will turn off when earbuds are fully charged.</p></div>	<div data-bbox="2539 158 3145 191"><p>Charging the Case:</p></div> <div data-bbox="2539 191 3145 278"><p>1. Connect the C-Type cable to the case and the USB end to a 5V power source.</p></div> <div data-bbox="2539 278 3145 333"><p>2. The Red light indicator in the front of the charging case will start blinking.</p></div> <div data-bbox="2539 333 3145 420"><p>3. When the case is fully charged, Red light will be steady. Remove the charging case from the power supply.</p></div> <div data-bbox="2539 420 3145 453"><p>Caution</p></div> <div data-bbox="2539 453 3145 573"><p>Using incompatible USB cable or high voltage chargers can damage the product & void the product warranty. We strongly recommend using DC5V-1A chargers & the USB cable included in the package.</p></div> <div data-bbox="2539 573 3145 606"><p>Troubleshooting:</p></div> <div data-bbox="2539 606 3145 649"><p>Scenario 1: One Earbud is Not Working</p></div> <div data-bbox="2539 649 3145 737"><p>1. Place both the earbuds in the charging case.</p></div> <div data-bbox="2539 737 3145 769"><p>2. Take out both the earbuds together from the charging case.</p></div> <div data-bbox="2539 769 3145 824"><p>3. Wait until L & R earbud pair to each other. After successful matching, only 1 earbud will flash Blue & Red light.</p></div> <div data-bbox="2539 824 3145 891"><p>4. Turn ON the Bluetooth on your phone, search for "pTron TWS" & connect.</p></div>	<div data-bbox="3145 158 3747 191"><p>Troubleshooting</p></div> <div data-bbox="3145 191 3747 223"><p>Scenario 2: Earbuds Not Connecting/Scanning</p></div> <div data-bbox="3145 223 3747 442"><p>1. Place both the earbuds in the charging case.</p><p>2. Take out both the earbuds together from the charging case.</p><p>3. Restart your Bluetooth device or phone.</p><p>4. Now, search for "pTron TWS" on your Bluetooth device & connect.</p></div> <div data-bbox="3145 442 3747 475"><p>Troubleshooting</p></div> <div data-bbox="3145 475 3747 507"><p>Scenario 3: Earbuds Disconnecting During a Phone Call</p></div> <div data-bbox="3145 507 3747 660"><p>1. Charge earbuds 100% before use.</p><p>2. Restart the earbuds and reconnect with your device.</p></div> <div data-bbox="3145 660 3747 693"><p>Disclaimer:</p></div> <div data-bbox="3145 693 3747 891"><p>The colors and specifications shown/mentioned in the user manual may differ from the actual product. Images shown are for representation purposes only. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners</p></div>
--	--	---	---	---	---