


Unpacking Check your product box for the following items. If there are any missing accessories, contact the local dealer where you purchased your product. The illustrations in this manual may differ from the actual product and item.


English


IN002043


## • Read Safety and Reference.

• For the power supply and power consumption, refer to the label attached to the product.










: Depending on model


۲








2


5














۲



HDMI IN/ARC

USB IN

⊡≫=

Ĩ

CAUTION -


on model.


Image shown may vary depending

All connection cables & devices

shown in the picture are not included along with the TV set.

۲






[G` kg

	A	B	C	D	6	<b>F</b> G
	(mm)				(kg)	
OLED55E9PTA	1226	753	220	50.3	25.8	16.4
OLED65E9PTA OLED65E9PVA	1447	877	220	50.3	33.6	20.8
Power requirement			AC 100-240 V ~ 50 / 60 Hz			

۲

۲



۲