




Quick Start Guide

SM81* SM86* SM90*

www.lg.com



Unpacking
Check your product box for the following items. If there are any missing accessories, contact the local dealer where you purchased your product. The illustrations in this manual may differ from the actual product and item.

: Depending on model


*Image may vary depending on models.





- Read **Safety and Reference**.
- \bullet For the power supply and power consumption, refer to the label attached to the product.

















































: Depending on model











	A	B	C	D	E	G	F-G
	(mm)					(kg)	
49SM8100PTA 49SM8100PVA 49SM8600PTA 49SM8600PVA	1096	710	263.1	640	63.6	15.5	14.0
55SM8100PTA 55SM8100PVA 55SM8600PTA 55SM8600PVA	1232	786	263.1	716	63.6	18.7	17.2
55SM9000PTA 55SM9000PVA	1232	781	263.1	709	62.5	19.1	17.6
65SM8100PTA 65SM8100PVA 65SM8600PTA 65SM8600PVA	1451	910	323.7	840	64	25.8	24.1
65SM9000PTA 65SM9000PVA	1455	906	323.7	835	62.5	28.1	26.4