



## Quick Start Guide

UM72\*  
UM73\*  
UM77\*  
UM78\*



### Unpacking

Check your product box for the following items. If there are any missing accessories, contact the local dealer where you purchased your product. The illustrations in this manual may differ from the actual product and item.

: Depending on model

\*Image may vary depending on models.












English


- Read **Safety and Reference**.
- For the power supply and power consumption, refer to the label attached to the product.




**CAUTION**  
Image shown may differ from your TV  
When attaching the stand to the TV set, place the screen facing down on a cushioned table or flat surface to protect the screen from scratches.



+ : Depending on model





**NOTE**  
Image shown may vary depending on model.  
All connection cables & devices shown in the picture are not included along with the TV set.


**NOTE**  
Some USB Hubs may not work. If a USB device connected using a USB Hub is not detected, connect it to the USB port on the TV directly.  
Connect the external power source if your USB is needed.

**NOTE**  
Do not look into the optical output port. Looking at the laser beam may damage your vision.  
Audio with ACP (Audio Copy Protection) function may block digital audio output.


**+** Depending on Model

**CAUTION**  
Image shown may vary depending on model.  
All connection cables & devices shown in the picture are not included along with the TV set.

OPTICAL DIGITAL AUDIO OUT



LAN




USB IN




HDMI IN



COMPONENT IN  
L/MONO AUDIO  
R  
VIDEO Y  
VIDEO B  
VIDEO G




AV IN  
L/MONO AUDIO  
R  
VIDEO Y  
VIDEO B  
VIDEO G




Satellite IN



ANTENNA / CABLE IN



PCMCIA CARD SLOT



**ARC (Audio Return Channel)**  
• An external audio device that supports SIMPLINK and ARC must be connected using HDMI IN/ARC port.  
• When connected with a high-speed HDMI cable, the external audio device that supports ARC outputs SPDIF audio without additional audio cable and supports the SIMPLINK function.

HDMI IN




HDMI IN/ARC




USB IN






**CAUTION**  
Image shown may vary depending on model.  
All connection cables & devices shown in the picture are not included along with the TV set.



**NOTE**  
Image shown may vary depending on model.



**NOTE**  
Image shown may vary depending on model.



**NOTE**  
Image shown may vary depending on model.

	A	B	C	D	E	F	F-G
	(mm)					(kg)	
49UM7300PTA 49UM7340PVA	1110	709	231	650	81.1	11.3	11.1
49UM7310PVD 49UM7290PTD	1110	705	235	650	81.1	11.3	11.1
50UM7300PTA 50UM7340PVA 50UM7700PTA	1130	722	231	663	86.3	11.5	11.3
50UM7290PTD	1130	719	235	663	86.3	11.4	11.3
55UM7300PTA 55UM7340PVA	1244	786	231	726	87.1	14.5	14.3
55UM7350PTD 55UM7300PTD 55UM7290PTD	1244	783	235	726	87.1	14.4	14.3
65UM7300PTA 65UM7340PVA	1463	914	269	850	87.8	21.6	21.3
65UM7290PTD	1463	910	255	850	87.8	21.5	21.3
70UM7300PTA 70UM7380PVA 70UM7880PTA	1578	984	299	913	91.1	31.4	30.7
Power requirement						AC 100-240 V - 50 / 60 Hz	