


User Guide

🐰 MadRabbit Liquid EarBuds

Specification

Model	MadRabbit Liquid EarBuds
Bluetooth Version	V5.1
Bluetooth Range	10 m
Drive Size	6 mm
Bluetooth Profiles	HFP / A2DP / AVRCP
Support Codec	AAC SBC
Battery Capacity (Case)	380 mAh
Battery	43 mAh
Input Rating	5V --- 400mA
Playtime Time	7 h at 70% volume
Total Play Time (With Case)	32 h at 70% volume
Charging Time	1 - 2 h
Charging Interface	Type-C
Water Resistance	IPX5




Choosing Eartips

Please try medium eartips first as they fit most people.



What's in the Box?



Charging Case



Ear Buds



Type-C Cable



User Guide



Catalogue



Eartips

Above pictures are for reference only. Practical accessories may vary.

First Time Pairing:


1. Pick both the earbuds from the Charging case.
2. Search for 'MadRabbit Liquid Buds' on your mobile and Tap to connect.

*Earbuds will power ON once picked. If not, please charge the case and try again.

Switch Paired Device:

1. Turn OFF Phone A's Bluetooth faculty.
2. Earbuds will auto disconnect and turn connectable.
3. On Phone B, search for 'MadRabbit Liquid Buds' and Tap to connect.


* Multi-Point Connection is not available. Earbuds will auto-reconnect to Phone B upon powering up again.



Reset:

1. Place the earbuds into the case.
2. Open the lid and keep touching both the earbuds for 10 secs or until both LEDs blink 5 times to reset the earbuds.

*Do not pick up earbuds during the process.



LED for Battery Level


LED will be turned Red for 4 secs when earbuds are placed into the case. If the battery level is low, LED will blink 4 times after earbuds are placed into the case.

User Instruction

How to Wear?




1. Please put on the earbuds properly and then adjust them to fit yourself.
2. Keep the microphone towards your mouth.



LED on Case

LED will blink Blue when the case is charging and turn solid Blue once it is topped up.

Function



Increase Volume : Single Tap Right Earbuds	Skip Track Backward : Keep touching the left panel for 1.5 secs
Decrease Volume : Single Tap Left Earbuds	Skip Track Forward : Keep touching the right panel for 1.5 secs
Power ON : Pick up earbuds to Power ON	Voice Assistant : Triple-touch the left panel
Power OFF : Place the earbuds into the case to Power OFF	Playback / Pause : Double-touch the left / right panel to Play / Pause
Answer / End Call : Double-touch Panel	Low Latency Mode : Triple-touch the right panel.
To Decline Call : Keep touching the panel for 1.5 secs	

FCC Statement

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced Radio / TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not approved by the party responsible for compliance could void the user's authority to operate the equipment.

Hazardous Substances and their contents in the item

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment can radiate radio frequency energy and, if not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Part Name	Hazardous Substances									
	Pb	Hg	Cd	Cr)NI	PBB	PBDE	DIBP	DEHP	DBP	BBP
Main box						0				
Battery	0	0	0	0	0	0	0	0	0	0
Ear tips	0	0	0	0	0	0	0	0	0	0
Accessories	0	0	0	0	0	0	0	0	0	0
Charging cable	x	0	0	0	0	0	0	0	0	0

This form is made by SJ/T 1364 regulation.

O: means that hazardous substance content in the homogeneous materials of this part is within the limits of (EU) 2015/863 regulation.

X: means that hazardous substance content in, at least, one certain homogeneous material of this part is beyond the limits of (EU) 2015/863 regulation, but there is no mature alternative in the industry at present, it still conforms to the EU ROHS Directive in the scope of the exemption.

Notes: Please arrange your using time properly as your hearing can be damaged by using the device for a long time.

Trademarks

MadRabbit word mark and logos are registered trademarks of Redster Commerce Pvt Ltd. Reproduction in whole or in part without written permission is prohibited. Other companies and products mentioned herein are trademarks of their respective owners.

MadRabbit Warranty

- The device is warranty for 12 months from the date of purchase. Repair and maintenance service are free during period.
- The warranty limitation:
 - Man-made damage.
 - Beyond the Warranty period.
 - Accessories damage due to improper use and maintenance.
 - Disassemble the device without manufacturer authority.



TM



Scan To Register A Warranty



Scan For A Video Guide